




## REA-90 and REA-90L ELECTROSTATIC SPRAY GUNS Dual Atomization Technology



### MODELS:

- 75785 - STANDARD (SOLVENT BASE)
- 75786 - STANDARD (WATERBORNE)
- 75979 - AVIATOR/MGS (SOLVENT BASE)
- 75982 - AVIATOR (WATERBORNE)



**IMPORTANT:** Before using this equipment, carefully read **SAFETY PRECAUTIONS**, starting on page 1, and all instructions in this manual. Keep this Service Manual for future reference.

Service Manual Price: \$30.00 (U.S.)

**NOTE:** This manual has been changed from revision **AH-94-04.4** to revision **AH-94-04.5**. Reasons for this change are noted under “Manual Change Summary” inside the back cover of this manual.

# CONTENTS

	<b>PAGE</b>
<b>SAFETY:</b>	<b>1-7</b>
SAFETY PRECAUTIONS.....	1
HAZARDS / SAFEGUARDS.....	2
<b>INTRODUCTION:</b>	<b>8-13</b>
GENERAL DESCRIPTION.....	8
REA-90 WITH AVIATOR.....	9
75785 SOLVENT BASE REA-90 STANDARD & 75979 SOLVENT BASE REA-90 AVIATOR / MGS.....	10
75786 WATERBORNE REA-90 STANDARD & 75982 WATERBORNE REA-90 AVIATOR.....	12
<b>INSTALLATION:</b>	<b>14-23</b>
75785 STANDARD SOLVENT BASE & 75979 AVIATOR / MGS SOLVENT BASE INSTALLATION.....	14
FILTERS.....	15
75786 STANDARD WATERBORNE & 75982 AVIATOR WATERBORNE INSTALLATION.....	16
ISOLATION SYSTEM INSTALLATION GUIDELINES.....	17
WATERBORNE HOSE FITTING INSTALLATION.....	18
FLUID HOSE FITTING INSTALLATION.....	19
AIR HOSE FITTING INSTALLATION.....	19
PAINT PREPARATION.....	19
SPRAY TECHNOLOGY CONVERSION PROCEDURE.....	20
SPRAY PATTERN ADJUSTMENT.....	21
GUN TO TARGET DISTANCE.....	21
AIR CAP / FLUID NOZZLE SELECTION CHART.....	22
AIR CAP / FLUID NOZZLE PERFORMANCE CHART.....	23
<b>MAINTENANCE:</b>	<b>24-57</b>
SUITABLE SOLVENTS FOR CLEANING REA-90 HANDGUNS.....	24
ROUTINE SCHEDULE.....	25
HANDGUN ASSEMBLY CLEANING PROCEDURE.....	26
FLUSHING PROCEDURES.....	28
GUN REPAIR.....	28
EQUIPMENT REQUIRED.....	28
TO REMOVE THE GUN FROM THE WORK SITE.....	29
AIR CAP.....	31
FLUID NOZZLE.....	31
NEEDLE/ELECTRODE.....	32
NEEDLE / ELECTRODE RESISTANCE TESTING.....	33

**(Continued On Next Page)**

	<b>PAGE</b>
<b>MAINTENANCE: (continued)</b>	<b>24-57</b>
BARREL ASSEMBLY.....	33
HOOK / TRANSFORMER ASSEMBLY.....	39
HOOK / TRANSFORMER ON/OFF SWITCH REPLACEMENT.....	41
HANDLE.....	42
FAN AIR VALVE.....	43
AIR VALVE.....	44
TRIGGER.....	45
NEEDLE SHAFT RETURN SPRING REPLACEMENT.....	46
LOW VOLTAGE CABLE PLUG ASSEMBLY REPLACEMENT.....	47
LOW VOLTAGE CABLE REPLACEMENT.....	48
FLUID TUBE (SOLVENT BASE GUNS).....	49
FLUID HOSE (SOLVENT BASE GUNS).....	50
FLUID HOSE (WATERBORNE GUNS).....	50
AIR LINE.....	52
FLUID TUBE BRACKET.....	52
TRIGGER ADJUSTMENT.....	53
FAN AIR ADJUSTMENT.....	54
FLUID DELIVERY ADJUSTMENT.....	54
ATOMIZING AIR ADJUSTMENT.....	54
TROUBLESHOOTING GUIDE.....	55
<b>PARTS IDENTIFICATION:</b>	<b>58-71</b>
75785 SOLVENT BASE (STANDARD) AND 75979 SOLVENT BASE (AVIATOR / MGS) / MODEL IDENTIFICATION / PARTS LIST.....	58
75786 WATERBORNE (STANDARD) AND 75982 WATERBORNE (AVIATOR) / MODEL IDENTIFICATION / PARTS LIST.....	64
RECOMMENDED SPARE PARTS.....	70
MISC. PARTS.....	70
SERVICE KITS.....	71
<b>WARRANTY POLICIES:</b>	<b>72</b>
LIMITED WARRANTY.....	72
<b>APPENDIX:</b>	<b>73-76</b>
PAINT AND SOLVENT SPECIFICATIONS.....	73
VISCOSITY CONVERSION CHART.....	74
VOLUMETRIC CONTENT OF HOSE OR TUBE.....	76

# SAFETY

## SAFETY PRECAUTIONS

Before operating, maintaining or servicing any ITW Ransburg electrostatic coating system, read and understand all of the technical and safety literature for your ITW Ransburg products. This manual contains information that is important for you to know and understand. This information relates to **USER SAFETY** and **PREVENTING EQUIPMENT PROBLEMS**. To help you recognize this information, we use the following symbols. Please pay particular attention to these sections.

**A WARNING!** states information to alert you to a situation that might cause serious injury if instructions are not followed.

**A CAUTION!** states information that tells how to prevent damage to equipment or how to avoid a situation that might cause minor injury.

**A NOTE** is information relevant to the procedure in progress.

While this manual lists standard specifications and service procedures, some minor deviations may be found between this literature and your equipment. Differences in local codes and plant requirements, material delivery requirements, etc., make such variations inevitable. Compare this manual with your system installation drawings and appropriate ITW Ransburg equipment manuals to reconcile such differences.



Careful study and continued use of this manual will provide a better understanding of the equipment and process, resulting in more efficient operation, longer trouble-free service and faster, easier troubleshooting. If you do not have the manuals and safety literature for your Ransburg system, contact your local ITW Ransburg representative or ITW Ransburg.



### **WARNING**


- ▶ The user **MUST** read and be familiar with the Safety Section in this manual and the ITW Ransburg safety literature therein identified.
- ▶ This manual **MUST** be read and thoroughly understood by **ALL** personnel who operate, clean or maintain this equipment! Special care should be taken to ensure that the **WARNINGS** and safety requirements for operating and servicing the equipment are followed. The user should be aware of and adhere to **ALL** local building and fire codes and ordinances as well as **NFPA 33 SAFETY STANDARD**, prior to installing, operating, and/or servicing this equipment.

### **WARNING**

- ▶ The hazards shown on the following page may occur during the normal use of this equipment. Please read the hazard chart beginning on page 2.

<b>AREA</b> Tells where hazards may occur.	<b>HAZARD</b> Tells what the hazard is.	<b>SAFEGUARDS</b> Tells how to avoid the hazard.
<p><b>Spray Area</b></p> 	<p><b>Fire Hazard</b></p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation. Frequent power supply shutdown indicates a problem in the system requiring correction.</p>	<p>Fire extinguishing equipment must be present in the spray area and tested periodically.</p> <p>Spray areas must be kept clean to prevent the accumulation of combustible residues.</p> <p>Smoking must never be allowed in the spray area.</p> <p>The high voltage supplied to the atomizer must be turned off prior to cleaning, flushing or maintenance.</p> <p>When using solvents for cleaning:</p> <p>Those used for equipment flushing should have flash points equal to or higher than those of the coating material.</p> <p>Those used for general cleaning must have flash points above 100°F (37.8°C).</p> <p>Spray booth ventilation must be kept at the rates required by NFPA 33, OSHA and local codes. In addition, ventilation must be maintained during cleaning operations using flammable or combustible solvents.</p> <p>Electrostatic arcing must be prevented.</p> <p>Test only in areas free of combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Non-factory replacement parts or unauthorized equipment modifications may cause fire or injury.</p> <p>If used, the key switch bypass is intended for use only during setup operations. Production should never be done with safety interlocks disabled.</p> <p>Never use equipment intended for use in waterborne installations to spray solvent based materials.</p> <p>The paint process and equipment should be set up and operated in accordance with NFPA 33, NEC, and OSHA requirements.</p>
<p><b>Toxic Substances</b></p> 	<p>Certain material may be harmful if inhaled, or if there is contact with the skin.</p>	<p>Follow the requirements of the Material Safety Data Sheet supplied by coating material manufacturer.</p> <p>Adequate exhaust must be provided to keep the air free of accumulations of toxic materials.</p> <p>Use a mask or respirator whenever there is a chance of inhaling sprayed materials. The mask must be compatible with the material being sprayed and its concentration. Equipment must be as prescribed by an industrial hygienist or safety expert, and be NIOSH approved.</p>

<b>AREA</b> Tells where hazards may occur.	<b>HAZARD</b> Tells what the hazard is.	<b>SAFEGUARDS</b> Tells how to avoid the hazard.
<b>Explosion Hazard / Incompatible Materials</b>  	Halogenated hydrocarbon solvents, for example: methylene chloride and 1,1,1, - Trichloroethane, are not chemically compatible with the aluminum that might be used in many system components. The chemical reaction caused by these solvents reacting with aluminum can become violent and lead to an equipment explosion.	The REA-90 and REA-90L require that aluminum inlet fittings be replaced with stainless steel. [See accessories list] Aluminum is widely used in other spray application equipment - such as material pumps, regulators, valves, etc. Check all other equipment items before use and make sure they can also be used safely with these solvents. Read the label or data sheet for the material you intend to spray. If in doubt as to whether or not a coating or cleaning material is compatible, contact your material supplier. Any other type of solvent may be used with aluminum equipment.
<b>Intended Use (Waterborne Only)</b>	Using coating materials and/or cleaning and flushing solvents which have flash points below 100°F (37.8°C) may cause a fire hazard.	This system is intended for use with waterborne coating formulations only.  Waterborne, waterbase and water reducible coatings are considered the same. Although they may not be highly flammable, their residues are considered combustible.
<b>Electrical Equipment</b>  	<p>High voltage equipment is utilized. Arcing in areas of flammable or combustible materials may occur. Personnel are exposed to high voltage during operation and maintenance.</p> <p>Protection against inadvertent arcing that may cause a fire or explosion is lost if safety circuits are disabled during operation.</p> <p>Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>An electrical arc can ignite coating materials and cause a fire or explosion.</p>	<p>The power supply, optional remote control cabinet, and all other electrical equipment must be located outside Class I or II, Division 1 and 2 hazardous areas. (Exception: AVIATOR series guns) Refer to NFPA 33.</p> <p>Turn the power supply OFF before working on the equipment.</p> <p>Test only in areas free of flammable or combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Production should never be done with the safety circuits disabled.</p> <p>Before turning the high voltage on, make sure no objects are within the sparking distance.</p>

<p><b>AREA</b> Tells where hazards may occur.</p>	<p><b>HAZARD</b> Tells what the hazard is.</p>	<p><b>SAFEGUARDS</b> Tells how to avoid the hazard.</p>
<p><b>Spray Area</b></p> 	<p>Electrostatic Arcing</p>	<p>Never operate the spray gun without properly grounding the following.</p> <p>A. Operators</p> <p>Operators must be grounded. Rubber soled insulating shoes should not be worn. Grounding leg straps may be used.</p> <p>Operators must maintain contact with the handle of the gun. If work gloves are used, the palm section should be cut out.</p> <p>Operators must remove from themselves all metal objects that are not grounded.</p> <p><b>NOTE:</b> REFER TO NFPA 33 REGARDING OPERATOR GROUNDING.</p> <p>B. Parts being sprayed. Resistance between the part and a grounded conveyor must not exceed 1 megohm.</p> <p>C. Every metal and conductive object in the spray area. This includes the booth, parts hangers, fire extinguishers, conductive flooring, etc.</p> <p>Grounded conductive flooring must be provided in the spray area.</p> <p>Turn off voltage at the power supply before flushing out, cleaning, or removing any parts from the gun.</p> <p>Provide proper protection for waterborne supply systems.</p> <p>Never install a spray gun into a fluid system using an isolated solvent supply.</p> <p>Always discharge Waterborne system capacitance prior to servicing.</p> <p>Do not touch gun electrode while gun is energized.</p>



<b>AREA</b> Tells where hazards may occur.	<b>HAZARD</b> Tells what the hazard is.	<b>SAFEGUARDS</b> Tells how to avoid the hazard.
<b>General Use and Maintenance</b>	<p>Improper operation or maintenance may create a hazard.</p> <p>Personnel must be properly trained in the use of this equipment.</p>	<p>Personnel must be given training in accordance with the requirements of NFPA 33.</p> <p>Instructions and safety precautions must be read and understood prior to using this equipment.</p> <p>Comply with appropriate local, state, and national codes governing ventilation, fire protection, operation maintenance, and housekeeping. Reference OSHA, NFPA 33, and your insurance company requirements.</p> <p>Always turn power to the power supply OFF, unplug the electrical cord from its outlet, and remove the front panel fuse, before opening the power supply door. If necessary, lock the power supply out so that it cannot be turned ON until the work is finished.</p> <p>Whenever removing high voltage cables from equipment, ground the contact end of the cable by holding the cable such that the contact touches earth ground for several seconds. Do not touch the contact until it has been grounded. This will reduce the possibility of residual charge causing electrical shock.</p> <p>The High Voltage Multiplier Assembly contains energy storage components that can cause serious shock injury, and therefore is not field repairable. Warranty will be voided if the High Voltage Multiplier seal is broken. If the High Voltage Multiplier is defective contact your authorized ITW Ransburg representative for exchange or repair.</p> <p>The High Voltage Multiplier and high voltage cable contain significant capacitance that will store charge. Allow approximately 10 seconds for this charge to bleed off before opening the cabinet door or removing the high voltage cable from the power supply or spray gun.</p>

<p><b>AREA</b> Tells where hazards may occur.</p>	<p><b>HAZARD</b> Tells what the hazard is.</p>	<p><b>SAFEGUARDS</b> Tells how to avoid the hazard.</p>
<p><b>General Use and Maintenance</b></p>	<p>Use of hand tools may cause cumulative trauma disorders (CTD's). CTD's or musculoskeletal disorders, involve damage to the hands, wrists, elbows, shoulders, neck and back. Carpal tunnel syndrome and tendinitis (such as tennis elbow or rotator cuff syndrome) are examples of CTD's.</p> <p>CTD's when using hand tools, tend to affect the upper extremities. Factors which may increase the risk of developing a CTD include:</p> <ol style="list-style-type: none"> <li>1. High frequency of the activity.</li> <li>2. Excessive force, such as gripping, pinching or pressing with the hands and fingers.</li> <li>3. Extreme or awkward finger, wrist or arm positions.</li> <li>4. Excessive duration of the activity.</li> <li>5. Tool vibration.</li> <li>6. Repeated pressure on a body part.</li> <li>7. Working in cold temperatures.</li> </ol>	<p>Risk is reduced by avoiding or lessening the listed hazards.</p> <p>CTD's can also be caused by such activities as sewing, golf, tennis and bowling, to name a few.</p> <p>Pain, tingling, or numbness in the shoulder, forearm, wrists, hands, or fingers, especially during the night, may be early symptoms of a CTD. Do not ignore them. Should you experience any such symptoms, see a physician immediately. Other early symptoms may include vague discomfort in the hand, loss of manual dexterity, and nonspecific pain in the arm. Ignoring early symptoms and continued repetitive use of the arm, wrist and hand can lead to serious disability.</p>

## **NOTES:**

# INTRODUCTION

## GENERAL DESCRIPTION

The REA process is an air-atomized method for electrostatically applying coatings to objects. The REA handgun system (technology) applies a high voltage DC charge to the applicator electrode, creating an electrostatic field between the atomizer and the target object.

The REA-90 or REA-90L Delta Electrostatic Spray Guns (see Figures 1 and 2) applies a -85 kV DC charge to the coating materials at the point of atomization. This electrostatic charge allows a more efficient, uniform application of coating material to the front, edges, sides, and back of products. It is highly suitable for applying coatings to a variety of surface configurations: large targets, small parts, tubular wares, concave and recessed parts, etc. Because it is a grounded fluid system (for solvent based systems), it is highly suitable for applying a wide range of solvent reduced coatings such as enamels, lacquers, epoxies, etc. The 75786 and 75982 models are available to accommodate waterborne materials.

The REA-90 and REA-90L electrostatic spray guns are transformable between air spray and HVLP spray technology. The REA-90 is designed for use as a conventional air spray (high-pressure) or high volume/low-pressure (HVLP) air spray to atomize the coating material. By changing a select few parts, the gun may be transformed to be operated in either spray mode. (See "Spray Technology Conversion Procedure" for details.)

A regulated pressure fluid system delivers coating material to the atomizer. At the time of triggering the applicator, fan and atomization air is introduced, which atomizes the coating material into a spray mist. The atomized spray particles under the influence of the electrostatic field become electrically charged. The charged particles are attracted to, and deposited on, the tar-

get object. The forces between the charged particles and the grounded target are sufficient to turn most normal overspray around and deposit it on the back surface of the target. Therefore, a high percentage of the coating is deposited on the target.

One of the many features of the REA handgun system is that the electrical energy, which is available from the resistive charging electrode, is limited to the optimum level of safety and efficiency.

This system is incapable of releasing sufficient electrical or thermal energy during normal operating conditions to cause ignition of specific hazardous materials in their most easily ignited concentrations in air (See NFPA 33 Regulations).

The control unit provides low voltage output to the gun and contains controls for AC on/off, high voltage adjust, kV and micro amp meter.

As the gun electrode approaches ground, the control unit and gun circuitry cause the high voltage and current to "fold back" and decrease towards zero for models 75785, 75979, and 75982. For models 75786, the fold back circuitry in the control unit has been turned off to provide maximum voltage for waterborne applications.

### **WARNING**

- ▶ Never use a standard solvent base handgun system (75785 or 75979) on a standard waterborne control unit. Failure to comply may cause damage to equipment and/or risk of fire and injury.

### **WARNING**

- ▶ Never use a waterborne (75786 or 75982) REA-90 system to spray solvent reduced coating materials. Failure to comply may cause damage to equipment and/or risk of fire and injury.

**! WARNING**

► When more than one waterborne gun is fed from a common isolated supply, there is a potential for electrical energy discharge through any other guns when one gun is triggered. Depending upon the system capacity, this discharge could be hazardous.

## **REA-90 WITH AVIATOR™**

The REA-90 may be used with the AVIATOR power generator in hazardous locations. This equipment meets Class 1, Division 1, and Group D hazardous location requirements. This allows moving the REA-90 power source inside most spray booths or areas where the standard control unit may not be conveniently located. Examples are airplane hangars, etc.

## **NOTES:**

## 75785 SOLVENT BASE REA-90 STANDARD

### SPECIFICATIONS

#### Environmental / Physical

<b>Gun Length:</b>	11 inches
<b>Weight:</b>	28 ounces
<b>Hose &amp; Cable Lengths:</b>	36 ft (Optional: 50, 75, and 100 ft)
<b>Atomizer Assembly (Std):</b>	4907-45, 4904-65R Air Spray 75601-00, 75600-01 HVLP

#### Electrical

<b>Operating Voltage:</b>	85 kV DC (-) maximum
<b>Current Output:</b>	90 microamperes maximum (foldback)

**Paint Resistance:\*** .1 MΩ to ∞  
\*(Use Model No. 76652, Test Equipment)

**Part Sprayability:** Determine sprayability of part to be coated using 76652, Test Equipment (see TE-98-01).

#### Mechanical

**Fluid Flow Capacity:** 1000 cc/minute\*\*

#### Operating Pressure (Air Spray)

<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	16 CFM @ 50 psi

#### Operating Pressure (HVLP Spray)

<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	22 CFM @ 50 psi (handle input) for 10 psi nozzle output

\*\* This reflects the maximum fluid volume the gun can deliver. The maximum spray volume that can be atomized depends on fluid rheology, spray technology, and finish quality required.

## 75979 SOLVENT BASE REA-90 AVIATOR/MGS™

### SPECIFICATIONS

#### Environmental / Physical

<b>Gun Length:</b>	11 inches
<b>Weight:</b>	28 ounces
<b>Hose &amp; Cable Lengths:</b>	36 ft (Optional: 50, 75, and 100 ft)
<b>Atomizer Assembly (Std):</b>	4907-45, 4904-65R Air Spray 75601-00, 75600-01 HVLP

#### Electrical

<b>Operating Voltage:</b>	85 kV DC (-) maximum
<b>Current Output:</b>	90 microamperes maximum (foldback)

**Paint Resistance:\*** .1 MΩ to ∞  
\*(Use Model No. 76652, Test Equipment)

**Part Sprayability:** Determine sprayability of part to be coated using 76652, Test Equipment (see TE-98-01).

#### Mechanical

**Fluid Flow Capacity:** 1000 cc/minute\*\*

#### Operating Pressure (Air Spray)


<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	16 CFM @ 50 psi

#### Operating Pressure (HVLP Spray)

<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	22 CFM @ 50 psi (handle input) for 10 psi nozzle output

\*\* This reflects the maximum fluid volume the gun can deliver. The maximum spray volume that can be atomized depends on fluid rheology, spray technology, and finish quality required.

**GUN:**  
REA-90 (75785S & 75979S)  
REA90L (75785L & 75979L)



**Figure 1: REA-90 and REA-90L Standard & AVIATOR/MGS Solventborne Electrostatic Spray Gun Features**

## 75786 WATERBORNE REA-90 STANDARD

### SPECIFICATIONS

#### Environmental / Physical

<b>Gun Length:</b>	11 inches
<b>Weight:</b>	28 ounces
<b>Hose &amp; Cable Lengths:</b>	36 ft (Optional: 50 and 75 ft)
<b>Atomizer Assembly (Std):</b>	4907-45, 4904-65R Air Spray 75601-00, 75600-01 HVLP

#### Electrical

<b>Operating Voltage:</b>	85 kV DC (-) maximum
<b>Current Output:</b>	150 microamperes maximum (no foldback)
<b>Part Sprayability:</b>	Determine sprayability of part to be coated using 76652, Test Equipment (see TE-98-01).

#### Mechanical

<b>Fluid Flow Capacity:</b>	1000 cc/minute**
<b>Operating Pressure (Air Spray)</b>	
<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	16 CFM @ 50 psi
<b>Operating Pressure (HVLP Spray)</b>	
<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	22 CFM @ 50 psi (handle input) for 10 psi nozzle output

\*\* This reflects the maximum fluid volume the gun can deliver. The maximum spray volume that can be atomized depends on fluid rheology, spray technology, and finish quality required.

## 75982 WATERBORNE REA-90 AVIATOR

### SPECIFICATIONS

#### Environmental / Physical

<b>Gun Length:</b>	11 inches
<b>Weight:</b>	28 ounces
<b>Hose &amp; Cable Lengths:</b>	36 ft (Optional: 50 and 75 ft)
<b>Atomizer Assembly (Std):</b>	4907-45, 4904-65R Air Spray 75601-00, 75600-01 HVLP

#### Electrical

<b>Operating Voltage:</b>	85 kV DC (-) maximum
<b>Current Output:</b>	90 microamperes maximum (foldback)
<b>Part Sprayability:</b>	Determine sprayability of part to be coated using 76652, Test Equipment (see TE-98-01).


#### Mechanical

<b>Fluid Flow Capacity:</b>	1000 cc/minute**
<b>Operating Pressure (Air Spray)</b>	
<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	16 CFM @ 50 psi
<b>Operating Pressure (HVLP Spray)</b>	
<b>Fluid:</b>	0-100 psi
<b>Air:</b>	0-100 psi
<b>Consumption:</b>	22 CFM @ 50 psi (handle input) for 10 psi nozzle output

\*\* This reflects the maximum fluid volume the gun can deliver. The maximum spray volume that can be atomized depends on fluid rheology, spray technology, and finish quality required.



**GUN:**  
REA-90 (75786S & 75982S)  
REA90L (75786L & 75982L)



**Figure 2: REA-90 and REA-90L Standard & AVIATOR Waterborne Electrostatic Spray Gun Features**

# INSTALLATION

## 75785 STANDARD SOLVENT BASE & 75979 AVIATOR/MGS SOLVENT BASE INSTALLATION

### WARNING

► Installation of the equipment **MUST** be in compliance with all Federal, State, and Local Codes. Prior to installation, all personnel should read and understand the National Fire Protection Association Bulletin No. 33, the Occupational Safety and Health Act of 1970, and ITW Ransburg Bulletin IL-247 "Operating Your Electrostatic Coating System Safely".

### WARNING

► **NEVER** wrap the applicator, associated valves and tubing, and supporting hardware in plastic to keep it clean. A surface charge may build up on the plastic surface and discharge to the nearest grounded object. Efficiency of the applicator will also be reduced and damage or failure of the applicator components may occur. **WRAPPING THE APPLICATOR IN PLASTIC WILL VOID WARRANTY.**

### Location of Control Unit (Non-AVIATOR Units)

Install the low voltage control unit at least 3 feet (0.9m) outside the spray area and/or in accordance with federal, state, and local codes. Refer to the low voltage control unit manual for mounting details. The control unit can be wired through conduit or with a line cord depending upon application requirements and codes.

The control unit **MAY** be connected through conduit to an explosion-proof switch (to turn high voltage on and off) and explosion-proof indicator light (indicates status of control unit) within the hazardous area for the convenience of the operator.

### Location of Control Unit (AVIATOR Units)

The AVIATOR may be located within the hazardous area. It may be mounted on a booth wall, pump cart, or other suitable places. Refer to the AVIATOR Power Generator manual, CP-97-01, for details on its installation.


The air supply to the AVIATOR Power Generator must be interlocked with the exhaust air for the spray area. If a conveyor system is used, then the air supply must be interlocked with it also.

### Routing of Low Voltage Cable

Position the spray gun in the spray area and route the low voltage cable to the control unit. The cable should be routed so that it is not damaged by foot and vehicle traffic and also so that it is not close to areas of high temperature (129°F+). The operator should have free movement of the gun and all bend radius of the cable should not be less than 6 inches (15 cm). Connect the low voltage cable to the control unit and hand tighten the retaining nut. If during the routing of the low voltage cable it is required to remove it from the spray gun, care should be taken when reinstalling it back that the retaining nut is wrench tight and the nut cannot be removed by hand.

### CAUTION

► Do **NOT** overtighten the low voltage connection at the handgun. The plastic parts could be damaged.



**Figure 3: Typical REA Handgun Installation**

**! WARNING**

► The electrical discharge that is available from the charging electrode must not exceed 0.25 mJ of energy. To achieve this limit, any flow of energy from the paint supply through the paint line to the gun electrode must be prevented by grounding the paint line at the gun handle.

Verify that the gun handle is actually grounded before operating it! This is done with a fully connected and operational system, by placing one lead of an ohmmeter to the handle and the other to the building electrical ground (cold water pipe, building structure, steel, etc.). This reading should be essentially zero.

If a greater reading is obtained, check that the control unit is grounded. See the control unit manual for grounding procedure.

**! WARNING**

► When installing the AVIATOR Power Generator, the air supply to the generator must be interlocked with the booth exhaust air and the conveyor system.

**FILTERS**

1. Install an air filter assembly on the air inlet of the control unit. Screw the fitting into the filter inlet. The filter **MUST** be installed with the arrow pointing in the direction of flow. Refer to the appropriate filter assembly manual for installation instructions.

**! CAUTION**

► An air filter **MUST** be installed to permit proper functioning of the air flow switch inside the control unit.

2. ITW Ransburg recommends that a fluid filter be installed at the output of the fluid supply (pressure pot, pump, circulating system, etc.). It is the end users responsibility to install a filter that meets their system's requirements.

## 75786 STANDARD WATERBORNE & 75982 AVIATOR WATERBORNE INSTALLATION

### **! WARNING**

- ▶ Installation of the equipment **MUST** be in compliance with all Federal, State, and Local Codes. Prior to installation, all personnel should read and understand the National Fire Protection Association Bulletin No. 33, the Occupational Safety and Health Act of 1970, and ITW Ransburg Bulletin IL-247 "Operating Your Electrostatic Coating System Safely".
- ▶ The control unit **MUST** be located outside of the spray area.
- ▶ The fluid lines and fluid sources **MUST** be isolated from ground.
- ▶ Personnel **MUST** be **GROUND**ED to prevent a shock or spark during electrostatic operation.
- ▶ Install and route the hoses and cable so they are **NOT** exposed to temperatures in excess of 120° F and so that all hose and cable bends are **NO LESS** than a 6-inch (15cm) radius. Failure to comply with these parameters could cause equipment malfunction that might create **HAZARDOUS CONDITIONS!**
- ▶ Install only one spray gun per isolated fluid supply system.

### **! WARNING**

- ▶ **NEVER** wrap the applicator, associated valves and tubing, and supporting hardware in plastic to keep it clean. A surface charge may build up on the plastic surface and discharge to the nearest grounded object. Efficiency of the applicator will also be reduced and damage or failure of the applicator components may occur. **WRAPPING THE APPLICATOR IN PLASTIC WILL VOID WARRANTY.**

### Location of Control Unit (Non-AVIATOR Units)

Position the low voltage control unit at least 3 feet (0.9m) outside the spray area and in accordance with federal, state, and local codes. Refer to the low voltage control unit manual for mounting details. The control unit can be wired through conduit or with a line cord depending upon application requirements and codes.

The control unit **MAY** be connected through conduit to an explosion-proof switch (to turn high voltage on and off) and explosion-proof indicator light (indicates status of control unit) within the hazardous area for the convenience of the operator.

### Location of Control Unit (AVIATOR Units)

The AVIATOR may be located within the hazardous area. It may be mounted on a booth wall, pump cart, or other suitable places. Refer to the AVIATOR Power Generator manual, CP-97-01, for details on its installation.

The air supply to the AVIATOR Power Generator must be interlocked with the exhaust air for the spray area. If a conveyor system is used, then the air supply must be interlocked with it also.

### Routing of Low Voltage Cable

Position the spray gun in the spray area and route the low voltage cable to the control unit. The cable should be routed so that it is not damaged by foot and vehicle traffic and also so that it is not close to areas of high temperature (129°F+). The operator should have free movement of the gun and all bend radius of the cable should not be less than 6 inches (15 cm). Connect the low voltage cable to the control unit and hand tighten the retaining nut. If during the routing of the low voltage cable it is required to remove it from the spray gun, care should be taken when reinstalling it back that the retaining nut is wrench tight and cannot be removed by hand.

## ISOLATION SYSTEM INSTALLATION GUIDELINES

Using waterborne coating with electrostatic equipment requires that the fluid source be isolated from ground. Precautions should be taken to ensure operator safety and system efficiency. The following guidelines should be followed:

- The fluid lines and source **MUST** be isolated from ground. An Isolating Paint Stand or similar isolating (non-porous) material **MUST** be used. Never use wooden boxes, pallets, or boards for isolators as wood will absorb moisture and is a **poor** insulator.

### CAUTION

► Never use wood products, wooden boxes, pallets, or boards as an isolator. Wood contains moisture and is a poor insulator. Electrical current passing through these materials can ignite them, causing a hazardous condition.

- Isolation stand **MUST** be at least 18 inches from the grounded booth wall, chain link fence, or other grounded objects.
- Air hoses to the pressure pot or pump on the insulating stand should be nonconductive plastic. Many rubber hoses will have static grounding circuits or carbon content and are **NOT** suitable for this application.
- All charged (isolated) systems **MUST** be inside a fence or cage to prevent contact by personnel. An interlock system **MUST** be provided that interrupts high voltage flow to the applicator if the gate is opened.
- Air regulators for pots or pumps should be mounted remotely outside the fence or cage area to facilitate changes in pressure without shutting the system down.

- Grounding hooks at the cage **MUST** be used to ground the system when personnel are working close by.
- Fluid lines to the applicator **MUST** be protected from scraping and abrasion on the floor or sharp metal edges that could lead to voltage pin holing and loss of kV on the charged system.
- Cleanliness and maintenance are extremely critical.

## Routing of Air and Fluid Hoses

Starting at the handgun, route the air hose along the same path as the low voltage cable to the low voltage control unit. The fluid hose can be run with the low voltage cable and air hose or it can be separate and run to the fluid source. Do not expose the hoses to high temperatures (over 120°F) and/or conditions such as moving parts, foot traffic, vehicle traffic, etc.

Prior to connecting the air hose to the low voltage unit and the fluid hose to the fluid supply, adjust the hose and low voltage cable position at the handgun to relieve some strain on the low voltage cable. To do this follow the following procedure.

1. Disconnect the air hose from the handgun.
2. Position the air hose 1-inch (2.5 cm) away from the bottom of the handle.
3. Secure the air hose to the low voltage cable. Secure the two together at one additional location, about 12-16 inches (30-41 cm) back.
4. With a wrench, reconnect and secure the air hose to the handgun. (This should form a small loop in the low voltage cable.)
5. Secure the fluid hose to the air hose and low voltage cable as needed.

**! WARNING**

► When securing the air hose, fluid hose, and low voltage cable together, take care not to use items such as wire or anything that might cut into the hoses or cable. If wire ties are used, they should only be tight enough to secure the cable and not so tight that they might restrict fluid and air flow.

Adjust the length of the air hose to the low voltage controller and install the fitting to the hose (refer to "Air Hose Fitting Installation").

## WATERBORNE HOSE FITTING INSTALLATION

**For 75786 & 75982:** ITW Ransburg supplies the waterborne fluid hose factory pre-assembled to the gun unit. Standard hose lengths are 36, 50, and 75 feet. To modify the hose length, use the following procedures. All adjustments must be made at the supply end of the system.

1. Remove the male connector and swivel fitting from the end of the fluid hose by turning the nut of the male connector counterclockwise while holding its main body.
2. Remove the male connector nut from the fluid hose.
3. Determine the hose length that is needed and cut the hose off squarely.

**! WARNING**

► Special care must be taken when removing the sheathing from the fluid hose. Make sure all tools are very sharp and only score the surface of the sheath. Inserting the knife too deep can score the surface of the core material and lead to pin-holing and failure of the hose.

4. Carefully score the outer jacket linearly and then radially approximately 18 inches back from the cut end. Split the outer jacket along the linear score mark and peel it away from the inner sheath. Then remove the jacket completely by tearing along the radial score mark.
5. Lightly score the inner sheath linearly and then radially 1 inch from the outer jacket. Split the inner sheath along the linear score mark and peel it away from the core fluid hose. Then remove the sheath completely by tearing along the radial score mark.
6. Roll the inner sheath back over itself until it touches the outer jacket.
7. Cut approximately 1/4-inch of inner sheath off.
8. Roll the inner sheath forward until 1/4-inch is still rolled over itself.
9. Reinstall and tighten the fitting to the core tubing.

## FLUID HOSE FITTING INSTALLATION

### -REFER TO FIGURE 4

ITW Ransburg supplies a standard 36-foot hose. Optional hose lengths of 50, 75, 100, and 150 feet are available. To meet various length requirements, the hose fitting on one end has not been attached. Determine the hose length that is needed and cut the hose off squarely. Attach the other fitting as follows.

1. Lightly lubricate all threaded areas with dielectric grease or petroleum jelly.
2. Screw the ferrule counterclockwise onto hose until it bottoms. Then screw clockwise approximately 1/8-inch.

### NOTE

- ▶ The union stem will not seat if the hose is bottomed against the ferrule.




Figure 4: Fluid Hose Assembly

3. Install the nut over the union stem, lubricate the stem, and start the stem into the hose, using care not to catch the hose lining with the stem tip.
4. Using a 3/16-inch Allen wrench, screw the union stem into the hose until it bottoms against the ferrule.
5. Connect one end of the hose to the fluid fitting at the bottom of the gun handle and the other end to the appropriate fluid source.

## AIR HOSE FITTING INSTALLATION

### -REFER TO FIGURE 4

ITW Ransburg supplies a standard 36-foot hose. Optional hose lengths of 50, 75, 100, and 150 feet are available. To meet various length requirements, the hose fitting on one end has not been attached. Determine the hose length that is needed and cut the hose off squarely. Attach the other fitting using the same procedure used for the fluid hose fitting installation.

## PAINT PREPARATION

A proper paint mixture is essential to electrostatic operation. Paint test equipment may be obtained through your ITW Ransburg representative. Reference Technical Manual IL-259 "Paint Related Information for REA, REM, and M90 Guns" for paint formulation information. For further paint formulation and testing procedures, consult your ITW Ransburg representative and/or your paint supplier.

## SPRAY TECHNOLOGY CONVERSION PROCEDURE

1. Remove the existing retaining ring and air nozzle from the gun.
2. Using the special multi-purpose gun wrench, remove the fluid nozzle by turning counterclockwise to loosen.

### CAUTION

- ▶ To avoid damage to the fluid nozzle and electrode, the paint pressure and trigger return spring tension **MUST** be released by triggering the gun while removing or installing the fluid nozzle.

The gun barrel **MUST** be tilted front down to remove the fluid nozzle. Failure to do so may allow paint to enter the air passages, thereby reducing airflow and damaging the gun barrel cascade. Guns may be flushed in lieu of tilting. However, they must be either flushed or tilted down during nozzle removal!

3. With a blade screwdriver, remove the pressure reducer from the barrel by unscrewing it counterclockwise.
4. Install the new pressure reducer.
5. Install appropriate fluid nozzle, gently tightening into place using the special multi-purpose gun wrench.
6. Reinstall appropriate air cap and retaining ring. See Figure 5 for proper combination of air caps, fluid nozzles and pressure reducers.
7. Remove fan control valve assembly and replace with appropriate fan control valve assembly according to spray technology being used. Reference Figure 5 for proper fan control valve.

### NOTE

- ▶ Control knob of fan control valve must be adjusted to the rear most position to avoid valve and/or seat damage.

### NOTE

- ▶ To avoid cross threading the plastic handle, install the fan control valve by hand. Once properly aligned, complete the assembly procedure using a suitable wrench.

### NOTE

- ▶ Proper selection of a fan control valve is necessary to meet certain state codes requiring 10 psi maximum air pressure at the air cap when using HVLP technology. Special gauges and test nozzles are available to confirm the pressure output. (See "Service Kits", Figure 32, for these parts.)



## SPRAY PATTERN ADJUSTMENT

The spray pattern of fan atomizers is adjustable from a small circle to an elongated oval, approximately 10 to 18 inches of usable pattern when sprayed from a target distance of 8 to 12 inches. The swirl atomizer assemblies produce a round pattern from 5 to 9 inches in diameter. The fan control knob provides control of the pattern shaping air. Counterclockwise expands the pattern and clockwise reduces it. To change the spray pattern axis of fan atomizers from horizontal to vertical, loosen the retainer ring, rotate the air cap clockwise to the desired position, and gently tighten the ring.

### CAUTION

- ▶ A counterclockwise turn of the air cap may loosen the fluid nozzle and cause air to get into the paint or paint to cross over into the air passages.

## GUN TO TARGET DISTANCE

Hold the gun 6 to 12 inches maximum from the target for best operation (higher transfer efficiency will be achieved at the closer target distance). Trigger the gun fully to operate.

### NOTE

- ▶ See ITW Ransburg Bulletin IL-246 "REA Handgun Spray Techniques".

## NOTES:

<b>AIR CAP / FLUID NOZZLE SELECTION CHART - Air Spray (Fan Control Valve 18851-01)</b>				
<b>Air Cap Part #</b>	<b>Fluid Nozzle Part #</b>	<b>Orifice I.D.</b>	<b>Separate Retaining Ring</b>	<b>Pressure Reducer (Black)</b>
4904-65R	4907-44	0.055	73569-00	74963-02
4904-65R	4907-45	0.070	73569-00	74963-02
4904-65R	4907-46	0.042	73569-00	74963-02
4904-65R	4907-47	0.028	73569-00	74963-02
4904-65R	4907-48	0.047	73569-00	74963-02
4904-63	4907-44	0.055	73569-00	74963-02
4904-63	4907-45	0.070	73569-00	74963-02
4904-63	4907-46	0.042	73569-00	74963-02
4904-63	4907-47	0.028	73569-00	74963-02
4904-63	4907-48	0.047	73569-00	74963-02
4904-98	4907-44	0.055	73569-00	74963-02
4904-98	4907-45	0.070	73569-00	74963-02
4904-98	4907-46	0.042	73569-00	74963-02
4904-98	4907-47	0.028	73569-00	74963-02
4904-98	4907-48	0.047	73569-00	74963-02

<b>AIR CAP / FLUID NOZZLE SELECTION CHART - Round Spray (Fan Control Valve 18851-01)</b>				
<b>Air Cap Part #</b>	<b>Fluid Nozzle Part #</b>	<b>Orifice I.D.</b>	<b>Separate Retaining Ring</b>	<b>Pressure Reducer (Black)</b>
70899-00	70898-00	Swirl*	4903-00	74963-02
LREA0002	LREA0003	Round*	73569-00	74963-02
* Both round and swirl nozzles are limited to approximately 300 cc (10 oz) maximum fluid delivery per minute.				

<b>AIR CAP / FLUID NOZZLE SELECTION CHART - HVLP Spray (Fan Control Valve 75133-00)</b>				
<b>Air Cap Part #</b>	<b>Fluid Nozzle Part #</b>	<b>Orifice I.D.</b>	<b>Separate Retaining Ring</b>	<b>Pressure Reducer (Black)</b>
75601-00	75600-01	0.055	73569-00	74963-03
75756-00	75600-02	0.070	73569-00	74963-03
75756-00	75600-03	0.086	73569-00	74963-03

Figure 5: Air Cap / Fluid Nozzle Selection Chart

<b>AIR CAP / FLUID NOZZLE PERFORMANCE CHART</b>									
<b>Fluid Nozzle Part #</b>	<b>Orifice I.D. (in/mm)</b>	<b>Fluid Delivery* (ml/min)</b>	<b>Spray Type</b>	<b>Air Consumption** (SCFM/SCMM)</b>	<b>Air Pressure (psi/bars)</b>	<b>Air Cap</b>	<b>Pattern Size*** (inches)</b>	<b>Pressure Reducer</b>	<b>Guns</b>
4907-44	.055/1.4	600	Air Spray	14.8/.40	22/1.5	4904-65R	15±1/2	Black	REA-III, IV, 70, & 90
4907-44	.055/1.4	300	Air Spray	13.5/.38	37/2.6	4904-63	9-1/2±1	Black	
75600-01	.055/1.4	318	HVLP Spray	23.8/.81	10/.69	75601-00	10-3/4±1	White	
<p>* Material: Lacquer, 18 Sec. No. 4 Ford Cup @ 72°F. Results are material dependent.            ** Air Flow @ Air Pressure noted in next column.            *** Patterns at 8-inch target distance.</p>									

**Figure 6: Air Cap / Fluid Nozzle Performance Chart**

# MAINTENANCE

## SUITABLE SOLVENTS FOR CLEANING REA-90 HANDGUNS

When cleaning the REA-90 handgun, a suitable solvent for cleaning depends on the part(s) of the gun to be cleaned and the material that needs to be removed. ITW Ransburg recommends that all exterior cleaning be done with nonpolar solvents to prevent a conductive residue on critical components. We also understand that some of these solvents do not always meet the cleaning needs of some materials. If conductive polar solvents are used to clean the gun components, all residue must be removed using a nonconductive nonpolar solvent (i.e. high flash naphtha). If there are any questions as to what solvents are best for cleaning, contact your local ITW Ransburg distributor and/or your paint supplier.

The REA-90 handgun, air hoses, fluid hose, and low voltage cable assemblies should not be submerged or soaked in solvent. However, the outer surfaces of these items can be wiped with a suitable solvent. When the gun is disassembled into individual components, some of these items may be soaked in a suitable cleaning solvent. The items that cannot be soaked are noted throughout this manual. All o-ring and electrical components **cannot** be cleaned or soaked in any solvents.

### **WARNING**

- ▶ The user **MUST** read and be familiar with the safety instructions in this manual.
- ▶ If compressed air is used in cleaning, **REMEMBER** that high pressure air can be dangerous and should **NEVER** be used against the body. It can blind, deafen, and may even penetrate the skin. If used for cleaning equipment, the user should wear safety glasses.
- ▶ **ALWAYS** turn the control unit's power off or the supply air to the AVIATOR off prior to cleaning and servicing the equipment.
- ▶ Be **SURE** the power is **OFF** and the system is grounded before using solvent to clean **ANY** equipment.
- ▶ **DO NOT** operate a faulty gun!
- ▶ When using cleaning solvent, standard health and safety precautions should apply.
- ▶ Cleaning of the exterior surface of the handgun should be done with nonpolar solvents. If cleaning requires the use of polar solvents, the handgun should be wiped down with nonpolar solvent prior to going back into use. Using polar solvents will leave a semi-conductive film on the surface of the handgun that will effect efficiency of the gun and cause damage to the components.

## ROUTINE SCHEDULE

Follow these maintenance steps to extend the life of the gun and ensure efficient operation.

### Several Times Daily

- Turn the control unit power to OFF!
- Inspect the air cap for paint accumulation. Clean as frequently as necessary with a soft bristled brush and a suitable solvent.

#### CAUTION

► NEVER remove the fluid nozzle assembly while paint is in the gun or paint may enter into the air passages. Clogged or restricted air passages will cause poor atomization and/or electrical shorting. Air passages that are clogged with conductive material can lead to excessive current output levels and consequent low operating voltage or long-term electrical damage. Before undertaking any atomizer maintenance procedure, see "Atomizer Assembly Cleaning Procedure".

The gun barrel MUST be tilted front down to remove the fluid nozzle. Failure to do so may allow paint to enter the air passages, thereby reducing airflow and damaging the gun barrel/cascade. Guns may be flushed in lieu of tilting. However, they must be either flushed or tilted down during nozzle removal!

- Clean all insulating surfaces in the system. Remove paint accumulation from the exterior of the gun and low voltage cable with a solvent dampened cloth.

#### CAUTION

► NEVER soak or submerge the electrical components of the gun, i.e., barrel, hook, transformer or cable. Damage and failure may occur.

### Daily (or at start of each shift)

- Verify that ALL solvent safety containers are grounded!
- Check within 20 feet of the point of operation (of the gun) and remove or ground ALL loose or ungrounded objects.
- Inspect workholders for accumulated coating materials (and remove such accumulations).
- Check that atomizer assembly is clean and undamaged.
- Straighten the gun electrode if necessary.

#### CAUTION

► When straightening the electrode be careful not to distort fluid nozzle orifice.

- Clean the fluid filter, if used.
- Turn the control unit power ON. Its green pilot should light.
- Run a current/voltage output test.

### Electrical Current Output Test

1. Turn the paint supply OFF.
2. Trigger the gun (high voltage ON).
3. Slowly approach the gun electrode to any grounded object and make contact.
4. Monitor the current output reading on the voltage supply meter as the gun approaches ground:

#### For Standard/MGS solvent units:

- a.) kV should fold back and be near zero at contact.
- b.) Current should increase to near 80  $\mu$ a and fold back to 20  $\mu$ a or less at contact.

**For Standard waterborne units:**

- a.) kV should approach zero at contact.
- b.) Current should increase to near 120  $\mu$ a at contact.

**For 75983-02 AVIATOR units:**

- a.) Transformer light should become very dim in illumination power.

If the reading is outside of the acceptable range, do NOT use the gun until the problem has been corrected (see Figure 28, "Troubleshooting Guide").

- 5. Release the trigger (high voltage OFF) and turn the control unit power OFF.

**Shutdown (or at end of each shift)**

- 1. Turn the control unit power OFF / turn OFF supply air to AVIATOR generator.
- 2. Turn the paint supply OFF.
- 3. Turn the atomizing and fan air OFF.
- 4. Wipe the gun, cable, and hoses with a rag and a suitable cleaning solvent.
- 5. Flush the lines and allow the solvent to remain in the lines unpressured (see "Flushing Procedures" in the "Maintenance" section).

**NOTE**

► If production downtime is to be short, the fluid lines may not require flushing, depending on the coating material being used. If the solids in the material settle slowly, the lines will not need to be flushed as soon after shutdown as with fast settling solids. The paint being used and the length of downtime will determine the need for flushing. Metallic paint and primer will require flushing sooner than other types of coating materials.

**CAUTION**

- If the coating material is fast settling and the fluid lines are not flushed soon enough, the internal passages may become clogged. This can lead to excessive downtime for repair.

**Weekly**

- Check the entire system for damage, leaks, and paint accumulation.
- Clean the atomizer assembly.

**HANDGUN ASSEMBLY  
CLEANING PROCEDURE**

**Routine Cleaning  
Equipment Needed**

- An appropriate solvent
- A solvent safety container (grounded)
- A small soft-bristled brush
- The ITW Ransburg special multi-purpose gun wrench

**CAUTION**

- To avoid damage to the fluid nozzle, needle/electrode, the paint pressure MUST be released by triggering the gun prior to removing the tip.
- The gun barrel MUST be tilted front down to remove the fluid nozzle. Failure to do so may allow paint to enter the air passages, thereby reducing airflow and damaging the gun barrel/cascade. Guns may be flushed in lieu of tilting. However, they must be either flushed or tilted down during nozzle removal!
- The control unit power MUST be off when removing the nozzles and/or during any gun maintenance.

**! CAUTION**

- ▶ When installing or removing the fluid nozzle, the gun **MUST** be triggered. Failure to do so may cause damage to the electrode or fluid nozzle. Such damage can result in fluid leaks around the sealing area of these components.
- ▶ Using any tool other than the ITW Ransburg multi-purpose gun wrench to remove or install the fluid nozzle may cause damage.

For efficient electrostatic operation, keep the gun's exterior and low voltage cable free of paint accumulation. This prevents the loss of voltage to ground with a resultant reduction in transfer efficiency. Paint accumulation in and around the air cap nozzles will reduce atomization quality. Clean the air cap using clean solvent and a soft bristle brush as often as needed to ensure good atomization.

**! WARNING**

- ▶ **NEVER** wrap the applicator, associated valves and tubing, and supporting hardware in plastic to keep it clean. A surface charge may build up on the plastic surface and discharge to the nearest grounded object. Efficiency of the applicator will also be reduced and damage or failure of the applicator components may occur. **WRAPPING THE APPLICATOR IN PLASTIC WILL VOID WARRANTY.**

Proceed as follows:

1. Turn OFF the control unit power / turn OFF supply air to the AVIATOR power generator.
2. Release the trigger.
3. Turn the paint flow OFF. Properly discharge all stored electrical energy from the waterborne system components.
4. See "Gun Repair" in the "Maintenance" section for disassembly procedures.

**! WARNING**

- ▶ Any broken or damaged components should be replaced. Any damage to the gun may result in UNSAFE operating conditions.

5. Clean the gun and associated parts with a soft brush and suitable solvent.

**! CAUTION**

- ▶ Metal tools and wire brushes must **NEVER** be used. **NEVER** use a cleaning tool that is harder than the plastic parts. If a deposit cannot be removed with the solvent and a rag or the soft brush, soak the part in the solvent **ONLY** until the deposit can be removed! **NEVER** soak the gun body, barrel, or hook transformer!

## FLUSHING PROCEDURES

1. Turn OFF the control unit power / turn OFF supply air to the AVIATOR power generator.
2. Turn the paint supply OFF.
3. Turn the atomizing air supply OFF. Properly discharge all stored electrical energy from the waterborne system components.
4. Tilt the gun down and trigger until it is clear of paint.
5. Connect the solvent supply.
6. Run solvent through the system until it runs clear.
7. Disconnect the solvent supply.
8. Trigger the gun until it is clear of solvent. After the preceding steps are complete, the gun is ready for color change, storage, or maintenance.

### CAUTION

- ▶ Do NOT allow the fluid lines to stand empty without flushing first! This will cause dried paint flaking and clogging of the fluid lines, gun passages, and/or nozzles.

## GUN REPAIR

All repairs should be made on a clean, flat surface. If a vise is used to hold parts during service or repair, DO NOT clamp onto plastic parts and always pad the vise jaws!

The following parts should be thoroughly packed with dielectric grease (LSCH0009-00) leaving NO air space or voids when assembling.

- All rubber o-rings (Teflon o-rings do not need lubrication)
- Needle Shaft Assembly 78627-04
- Packing Tube 18842-01
- Transformer/Hook Assembly 71202-XX
- Cartridge Assembly, Non-Adjustable 78626-00
- Air Valve Rod Assembly 79310-00

Apply sealant (7969-10) to the external threads of the following parts when assembling:

- Nut, Air Valve Retaining 78635-00
- Cap, Air Valve 79317-00
- Nut, Fan Valve Retaining 18851-01 / 75133-00
- Cap, Spring 77015-00

## EQUIPMENT REQUIRED

- Special Multi-Purpose Gun Wrench (19749-00)
- 3/32-inch Allen Wrench for Set Screws (2)
- 3/16-inch Allen Wrench for Hose Fittings
- Open End Wrenches: 15/16, 7/8 11/16, 9/16, 7/16, 3/4, 3/8, and 1/4-inch
- Screwdriver (blade)
- Dielectric Grease (LSCH0009-00)
- Sealant, medium strength (7969-10)
- Plastic or Wood Dowel Rod, 5/16-inch diameter



## TO REMOVE THE GUN FROM THE WORK SITE

**CAUTION**

- ▶ ALWAYS remove the gun from the work site for service or repair!
- ▶ DO NOT use any silicone lubricants in order to avoid paint defects.

### Solvent Base Guns

-REFER TO FIGURE 7

1. Flush the gun. (Refer to "Flushing Procedures".)
2. With a wrench, loosen and unscrew the fluid hose nut. Remove the fluid hose assembly.

3. With a wrench, lock the air fitting in place and loosen the air hose nut using a second wrench. Completely unscrew the nut and remove the air hose assembly.

**NOTE**

- ▶ If the low voltage cable is to be replaced, see "Low Voltage Cable Replacement".

4. Loosen the low voltage cable nut from the plug assembly with a wrench and unscrew the nut by hand. Remove the low voltage cable by pulling it from the low voltage cable plug assembly.
5. Remove the gun from the work site.




Figure 7: Solvent Base Gun Connections

## Waterborne Guns

### -REFER TO FIGURE 8

1. Flush the gun. (Refer to "Flushing Procedures".)
2. With an adjustable wrench, loosen and unscrew the fluid tube connector. Slide the nut back and down the fluid tube.
3. Loosen the fluid tube nut and unscrew it from the fluid tube fitting.
4. Loosen and unscrew the fluid tube fitting nut from the fluid tube fitting.
5. Pull the fluid hose assembly out of the barrel, removing the spacer, ferrule, and fluid tube connector. Then continue pulling the fluid hose assembly through the bracket, removing the fluid tube nut, conductive ferrule, and fitting nut.

6. With a wrench, lock the air fitting in place and loosen the air hose nut using a second wrench. Completely unscrew the nut and remove the air hose assembly.
  7. Loosen the low voltage cable nut from the plug assembly with a wrench and unscrew the nut by hand. Remove the low voltage cable by pulling it from the plug assembly.
- NOTE**

► If the low voltage cable is to be replaced, see "Low Voltage Cable Replacement".
8. Remove the gun from the work site.

Item #	Description
26	Fluid Tube Bracket
59	Fluid Hose Assembly (Waterborne)
62	Fluid Tube Connector Nut
63	Nut & Ferrule
65	Nut
66	Fluid Hose Fitting
71	Air Hose Assembly
77	Low Voltage Cable




Figure 8: Waterborne Gun Connections

## AIR CAP

-REFER TO FIGURE 9

### Removal

1. While holding the air cap in place with one hand, loosen the retaining nut using the other hand.
2. Unscrew the retaining nut completely and remove the air cap.

### Cleaning and Inspection

1. Use a suitable solvent to clean the air cap. (Refer to "Suitable Solvents for Cleaning REA-90 Handguns".)
2. Examine the air cap for damage to the air horns, face, and any air passages. If any of these areas are damaged or worn, the air cap should be replaced.

### Reinstall

1. Check the fluid nozzle to ensure that it is tightly screwed into the barrel.
2. Place the air cap over the electrode wire of the needle/electrode and set it onto the fluid nozzle.
3. Place the retaining nut over the air cap and begin screwing it onto the barrel.
4. Before securing the retainer nut to the barrel, position the air cap for the desired spray pattern position.

## FLUID NOZZLE

-REFER TO FIGURE 9

### Removal

1. Remove the air cap from the gun. (Refer to "Air Cap - Removal".)
2. Tilt the gun forward and pull the trigger to make sure that all fluid in the gun is drained out.

**⚠ CAUTION**

► The gun barrel **MUST** be tilted front down to remove the fluid nozzle. Failure to do so may allow paint to enter the air passages, thereby reducing airflow and damaging the gun barrel. Guns may be flushed in lieu of tilting. However, they **MUST** be either flushed or tilted during nozzle removal!

3. While holding the gun assembly with the trigger pulled back, remove the fluid nozzle with the open-end of the special multi-purpose wrench.

### NOTE

- To keep the needle/electrode from unscrewing from the needle shaft, the gun's trigger should be actuated to pull the needle/electrode away from the fluid nozzle.




Figure 9: Air Cap, Fluid Nozzle, & Nut

## Cleaning and Inspection

1. Use a suitable solvent to clean the fluid nozzle. (Refer to "Suitable Solvents for Cleaning REA-90 Handguns".)
2. Examine the fluid nozzle for damage to the air passages and the fluid nozzle tip. Also, examine the needle seat for damage or wear. If any damaged or any worn areas are found, the fluid nozzle must be replaced.

### NOTE

- ▶ If the fluid nozzle is replaced, there is a good chance that the needle/electrode assembly will need to be replaced also. A worn needle/electrode assembly may not always seat well in a new fluid nozzle.

## Reinstall

1. Check the needle/electrode tightness on the needle shaft. If it is loose, tighten it. (Refer to "Needle/Electrode".)
2. With the gun trigger actuated, place the fluid nozzle over the needle/electrode and screw it into the barrel by hand.
3. Tighten it using the special multi-purpose wrench.

### NOTE

- ▶ DO NOT overtighten the fluid nozzle into the barrel. Doing so could damage or break the fluid nozzle or damage the thread of the barrel.

4. Install the air cap and retaining ring onto the gun. (Refer to "Air Cap - Reinstall".)

## NEEDLE / ELECTRODE

### Removal

1. Remove the air cap and fluid nozzle from the gun assembly. (Refer to "Air Cap - Removal" and "Fluid Nozzle - Removal".)
2. Secure the needle shaft at the rear of the barrel and unscrew the needle/electrode from the needle shaft.

### Cleaning and Inspection

1. Use a suitable solvent to clean the needle/electrode. (Refer to "Suitable Solvents for Cleaning REA-90 Handguns".)
2. Examine the needle/electrode for damage or wear. Pay special attention to the area where the wire electrode extends from the main body. This is a sealing surface that seats inside the fluid nozzle. If there are signs of wear in this area, both the needle/electrode and fluid nozzle must be replaced.
3. An electrical check of the needle/electrode must be done prior to reinstalling it into the gun assembly. (Refer to "Needle/Electrode Resistance Testing".)

### Reinstall

1. Secure the needle shaft at the rear of the barrel and screw the needle/electrode into place by hand.
2. Reinstall the fluid nozzle and air cap onto the barrel. (Refer to "Air Cap - Reinstall" and "Fluid Nozzle - Reinstall".)

## NEEDLE / ELECTRODE RESISTANCE TESTING

The electrical resistance of the needle/electrode should be tested periodically (typically on a weekly basis) or any time it is removed from the gun.




Figure 10: Testing Resistive Electrode

### To Test

1. Install the needle/electrode onto the front end of an available needle shaft. Be sure that the needle/electrode is completely seated for proper contact between the metal shaft and the threaded insert of the needle/electrode.
2. Using a VOM meter that will read 15 megohms accurately, connect the first meter lead to the metal needle shaft and the second lead to the needle/electrode wire. The needle/electrode resistance should be 14.5 to 19 megohms (nominal 15 megohms at 9 volts or 11 to 17 megohms at 1000 volts). Needle/electrodes outside these ranges must be replaced.

## BARREL ASSEMBLY

### NOTE

- If during pretesting it is found that the cascade section of the barrel is bad, repair of barrel is not an option. The only course of action is to replace the barrel assembly.

## Removal

1. While holding the air cap in place with one hand, loosen the retaining nut using the other hand.
2. Unscrew the retaining nut completely and remove the air cap.
3. Using a flat head screwdriver, remove the two shoulder screws that retain the trigger to the gun handle.
4. While holding the grounding spring (located under the trigger and over the air valve stem) back toward the handle, remove the trigger from the gun handle. Remove the grounding spring from the air valve stem.
5. Using an adjustable wrench, unscrew the fluid tube connector from the barrel and slide it down the fluid tube.
6. Use the special multi-purpose wrench to loosen the retaining nut that secures the barrel to the gun handle. After unscrewing the retaining ring, slide it forward onto the barrel.
7. Hold the gun handle and fluid tube so the barrel points downward. With the other hand, pull the barrel forward to separate it from the handle. Once the barrel has cleared of the handle, remove the spring from the spring retainer and set it aside. If the fluid tube does not come loose from the barrel, rotate the barrel back and forth on the axis of the fluid tube until it comes loose.
8. There is no need to remove the retaining ring or nut from the barrel unless they are damaged. If they are to be replaced, lift one end of retaining ring over the captive ridge and spiral it off the end of the barrel. Then the retaining nut can be removed.



### CAUTION

- Use care in removing the retaining ring. If it is spread too much it could break.

## Disassembly

1. Remove the trigger adjustment nut and spring retainer from the needle shaft using two 3/8-inch open-end wrenches.
2. Position the barrel so the front is facing down. Using the small spanner tool on the special multi-purpose wrench, unscrew the packing nut from the rear of the barrel by turning it counterclockwise.
3. Holding the barrel in one hand and with a firm pull, remove the needle shaft assembly from the packing chamber of the barrel. Trigger adjustment nut can be reinstalled for additional grip. If the needle shaft will not pull out of the barrel, use the following procedure:
  - a.) Remove the needle/electrode from the needle shaft.
  - b.) Pull the needle shaft from the rear of the barrel.
  - c.) Place the barrel on a work bench. Holding the barrel in one hand, with the front pointing upward, push a 5/16-inch diameter wooden or plastic dowel through the center bore of the barrel. This should push the cartridge seal assembly out the rear of the barrel.

4. Remove the trigger adjustment nut if it was required when pulling the needle shaft from the barrel packing chamber. Then remove the packing nut, spacer, rear seal retainer subassembly, and packing tube from the rear of the needle shaft. The spring-loaded u-cup and o-ring can now be removed from the rear seal retainer.

### NOTE

- If the spacer and seal retainer do not separate easily, wedge a knife blade between them and pry them apart.

5. Unscrew the needle/electrode from the front of the needle shaft.
6. Remove the cartridge seal assembly from the front of the needle shaft.




Figure 11: Cartridge Seal Assembly

7. Loosen the fluid nozzle using the special multi-purpose wrench and unscrew it by hand to remove.

## Cleaning and Inspection

1. Clean the packing chamber of the barrel with a suitable solvent and a soft bristle bottle brush. **Do not submerge or soak the barrel in solvent.** If the chamber has dry paint in it and cannot be cleaned out, the barrel **MUST BE REPLACED.**

### CAUTION

- During this operation, be CAREFUL that the interior surface of packing chamber is NOT damaged (marred or scratched)! This chamber is a seal area and the barrel/cascade assembly will have to be replaced if it is damaged.

**! WARNING**

- ▶ Soaking or submerging the barrel could allow solvents into the high voltage section of the barrel, leading to gun failure and/or possible dangerous conditions that could result in property damage and personnel injury.

2. Examine the plastic section of the needle shaft and the packing tube for signs of carbon tracking. Also inspect the air passages and packing chamber of the barrel for signs of scratches, additional carbon tracking, or dried paint. Shine a small flashlight into the front of the barrel to highlight any damage in these areas.


**! CAUTION**

- ▶ Barrels with dry paint, scratches, or high voltage tracking marks in the air and/or packing chamber passages **MUST BE REPLACED**. Neglecting to replace the barrel may lead to reduced gun efficiencies and premature component failure.

3. From time to time it is desirable to test the electrical integrity of the resistive electrode. See "Needle/Electrode Resistance Testing".

## Reassembly

-REFER TO FIGURES 12, 13, 14 & 15



Item #	Description
9	Electrode Assembly
11	Cartridge Seal Assembly
13	2-Piece Needle Shaft Assembly


Figure 12: Front Needle Shaft Assembly

1. Prior to installing the non-adjustable cartridge seal, fill the internal bore with dielectric grease. Then place the cartridge seal, with the black plastic section rearward, onto the front of the needle shaft. Then screw it on and over the external threads of the needle shaft. Once both internal o-rings have cleared the threads, slide it onto the sealing area.

**! CAUTION**

- ▶ Do NOT push the cartridge seal straight over the shaft threads. The threads will damage the internal o-rings and cause fluid leaks.

2. Screw the needle/electrode onto the front of the needle shaft and hand tighten.



Item #	Description
13	2-Piece Needle Shaft Assembly
14	Packing Tube
15	Seal Retainer
16	O-Ring
17	U-Cup
18	Spacer
20	Packing Nut
21	Trigger Adjustment Nut
82	Needle Shaft Spring Retainer

Figure 13: Rear Needle Shaft Assembly


3. Fill the inner diameter of the packing tube with dielectric grease.
4. Insert the needle shaft, rear section first, into the packing tube. Rotate the needle shaft while moving it back and forth inside the packing tube until fully inserted.

5. With your finger, wipe the excess grease from both ends of the packing tube. Using the excess grease, apply a thin film to the outer surface of the packing tube and to the external o-ring on the cartridge seal.

**NOTE**


► Be generous with the dielectric grease when applying it to the packing tube and needle shaft. This helps to remove air voids from this chamber. DO NOT apply so much grease that it creates an air lock during assembly of the gun.

6. Apply a light film of dielectric grease to the seal retainer o-ring and install it into the external groove.
7. Insert the spring loaded u-cup into the seal retainer (with the concave side facing outward). Use the short end of the spacer to seat the seal.
8. While holding the rear seal retainer sub-assembly and spacer together, place these components (with the spacer rearward) onto the rear of the needle shaft and slide them over the sealing area.
9. Place the packing nut (large bore first) on the rear needle shaft section.
10. Screw the trigger adjustment nut onto the rear needle shaft section with the hexagon rearward and the spring retainer with the hexagon forward. Do not lock the hexagon nuts in place.
11. Install the needle shaft subassembly into the packing chamber from the rear of the barrel with the needle/electrode forward.
12. Push the needle shaft subassembly forward until the packing nut will engage its mating thread in the barrel and screw it into place by hand approximately 3 turns.



**Figure 14: Needle Shaft Assembly into Barrel**

13. Pull the needle shaft rearward as far as it will go.
14. Install the fluid nozzle, air cap, and retaining nut. (Refer to "Air Cap" and "Fluid Nozzle".)
15. Tighten the packing nut using the spanner tool on the special multi-purpose gun wrench until it bottoms.



**Figure 15: Trigger Adjustment Nut Dimension**

16. Push the needle shaft forward until the needle/electrode seats into the fluid nozzle.
17. Adjust the trigger adjustment nut as far forward on the needle shaft as possible.
18. Adjust the needle shaft spring retainer until the rear of the hexagon is 11/16-inch from the rear surface of the barrel packing chamber (refer to Figure 15).



19. Hold the spring retainer in place and screw the front trigger adjustment nut rearward until contact is made. Use two 3/8-inch open-end wrenches to tighten and lock the adjustment nuts in place on the needle shaft.

**CAUTION**

► Do not overtighten the hexagon adjustment nuts or damage may occur to the plastic threads or the needle shaft may break. Finger tight is typically sufficient. (Maximum torque of 18-24 oz•in.)

### Attaching Barrel to Handle

1. If the barrel retaining nut has been removed, it will have to be reinstalled before the barrel can be attached to the handle.
2. Place the retaining nut over the rear of the barrel and slide it as far forward as possible.
3. Spread the retaining ring and place it onto the barrel. Starting at one end, lift the retaining ring over the captive ridge and spiral into place.

4. Place the large hole of the gasket over the needle shaft and onto the boss of the barrel packing chamber.
5. While holding the barrel with the air nozzle pointing downward, install the needle shaft spring into the spring retainer. Align the electrical connectors of the barrel with the mating holes in the hook/transformer assembly and the needle shaft spring with the spring recess in the handle. Slide the barrel into the handle cavity until it is seated against the gasket. Ensure the needle shaft spring did seat into the handle recess.
6. While holding the barrel in place, screw the retaining nut onto the handle by hand and then tighten using the special multi-purpose wrench.

### NOTE

- Torque the retaining ring to 8 to 10 lb•ft or after hand tightening, torque an additional 1/6 to 1/8 turn using the special multi-purpose wrench.

Item #	Description
4	Barrel
7	Retaining Nut
8	Retaining Ring
22	Gasket
23	Handle
25	Hook / Transformer
27	Grounding Spring
82	Needle Shaft Spring Retainer
83	Compression Spring




Figure 16: Barrel to Handle Assembly

7. Check the spacing between the back of the spring retainer and the handle. It should be about 1/8-inch. If not, check for one or more of the following:
  - Gasket has been left out
  - Loose retaining nut
  - Loose fluid nozzle
  - Improper adjustment of the trigger adjustment nut and spring retainer
8. Place the grounding spring over the air valve stem.
9. Pull the grounding spring back and slide the trigger into position.
10. Secure the trigger with the two shoulder screws.

**NOTE**

► The needle shaft travel **MUST** be checked. The air valve stem must be engaged and move back slightly before the trigger engages the trigger adjustment nut. If this does not occur then the trigger adjustment nut and/or the trigger set screw must be adjusted. The 11/16-inch dimension is only a starting place for trigger adjustment and can be altered to obtain proper triggering sequence.

**NOTES:**

## HOOK / TRANSFORMER ASSEMBLY




Figure 17: Hook/Transformer Removal

### Removal

- The following procedures must be performed prior to removing the hook/transformer assembly.
  - Barrel Removal from Gun
  - Low Voltage Cable Removal
  - Fluid Hose Removal and Fluid Tube Removal (for Solvent Base Guns) or Fluid Hose Removal (Waterborne Guns)
  - Low Voltage Cable Plug Assembly Removal
- Remove the gasket from the handle if it did not come out with the barrel.
- Slide the hook/transformer forward and out of the handle channel.

## Testing and Repair

### NOTE

► The hook/transformer can be tested using the Transformer Output Tester and following the guidelines of its instruction manual, TE-88-02. If the transformer output tester is not available, the following procedure can be used to test the hook/transformer.

- Prior to testing the hook/transformer, the following test procedures must be conducted.
  - Low Voltage Cable Test
  - Low Voltage Cable Plug Assembly Test





Figure 18: Hook/Transformer Test Setup Diagram

- Connect the low voltage cable to a control unit and a cable plug assembly (refer to Figure 18).
- Connect the low voltage cable and the plug assembly to the hook/transformer. This can be done without the handle on a workbench or with the hook/transformer, low voltage cable, and plug assembly installed into a handle. **DO NOT** perform this test with the barrel attached to the hook/transformer.

4. On the control unit, turn the high voltage adjustment knob fully counterclockwise.
5. Make sure that the on/off switch of the hook/transformer is in the "ON" position, if the unit has this option (refer to Figure 19).
6. Turn the control unit on and adjust the voltage knob clockwise to increase the voltage to the hook/transformer.
7. Watch the red lens at the rear of the hook/transformer. As the voltage is increased, the LED behind the lens will increase in intensity. Once the voltage control knob is turned fully clockwise, the LED should be at it's highest intensity.



**Figure 19: Hook/Transformers Switch Position**

8. If the LED does not light, check the position of the on/off switch. It must be in the ON position. If the switch is in the correct position, replace this unit (refer to "Hook Transformer On/Off Switch Replacement") and retest.
9. If the LED will not light after replacing the switch, the hook/transformer is bad and must be replaced.

## Replace LED Lens

1. If the lens that covers the LED of the hook/transformer is cracked or broken, the lens should be replaced.
2. With a spanner wrench, unscrew the lens from the hook/transformer.
3. Install a new replacement lens using a spanner wrench.

## Reinstall

1. Apply dielectric grease to the rails of the hook/transformer and the associated channel of the handle.
2. Slide the rails of the hook/transformer into the channels of the handle, red lens side first. Push the hook/transformer rearward until seated into handle chamber.
3. Check the alignment of the hook/transformer face to that of the handle face (they must be flush).
4. If they are not flush, remove the hook/transformer from the handle and adjust the set screw on the back of the hook/transformer.
  - a.) If the hook/transformer face protrudes beyond the handle face, turn the set screw clockwise.
  - b.) If the hook/transformer face is recessed, turn the set screw counterclockwise.

## **HOOK / TRANSFORMER ON/OFF SWITCH REPLACEMENT**

### **Removal**

1. With the hook transformer removed from the handle, locate a small set screw just under the on/off switch.
2. With a small screw driver, unscrew the set screw from the hook transformer until the on/off switch can be pushed out.

### **Cleaning and Inspection**

There is no reason to clean the on/off switch. The switch is not repairable and must be replaced.

### **Reinstall**

1. Apply a light coating of dielectric grease to the on/off switch.
2. With the hook transformer setting with the set screw facing upward and the LED lens facing toward you, slide the on/off switch into the hook transformer so that the slot in the switch is on the left side of the hook transformer and in line with the set screw.
3. Hold the on/off switch and screw the set screw into the hook transformer until it just contacts the switch body.
4. Check the action of the switch by sliding it back and forth in the hook transformer. The switch should slide back and forth with light resistance.
  - a.) If the on/off switch is hard to move, loosen the set screw.

- b.) If it moves when the hook transformer is tilted from side to side, tighten the set screw.
5. Retest the hook transformer prior to reinstalling into the handle. (Refer to "Hook/Transformer Assembly - Testing and Repair".)

## HANDLE

### Removal

1. Prior to working on the gun handle, the following procedures should be completed.
  - Removal from Service
  - Removal Fluid Tube and Fluid Hose (for Solvent Base Guns) or Fluid Hose (for Waterborne Guns)
  - Removal Air Hose
  - Removal Low Voltage Cable
  - Removal Low Voltage Cable Plug Assembly
  - Removal Trigger
  - Removal Barrel
  - Removal Fluid Tube Bracket
  - Removal Hook/Transformer
  - Removal Fan Air Screw
  - Removal Air Valve
  - Removal Trigger Stop
  
2. The handle can now be completely disassembled of all components. There are (5) pipe plugs that were installed at the factory and should not be removed.

### Cleaning and Inspection

1. The handle can be cleaned and/or soaked in a suitable solvent to remove all paint from the outer surfaces and the interior passages.
  
2. The handle is very durable and usually not damaged during normal operations. Examine the handle for cracks, chips, and/or broken parts. If any are noted the handle must be replaced.

## Assembly

1. To get the gun ready to be placed back into service, perform the following procedures.
  - Install Trigger Stop
  - Install Air Valve
  - Install Fan Air Screw
  - Install Hook/Transformer
  - Install Barrel to Handle
  - Install Fluid Tube Bracket
  - Install Trigger
  - Install Low Voltage Cable Plug Assembly
  - Install Low Voltage Cable
  - Install Air Hose
  - Install Fluid Tube and Fluid Hose (for Solvent Base Guns) or Fluid Hose for (Waterborne Guns)
  - Placing Gun Back in Service

## FAN AIR VALVE




Figure 20: Fan Air Screw

### Removal

#### -REFER TO FIGURE 20

1. Turn control knob to the open position (screwed fully out, counterclockwise).
2. With a 9/16-inch wrench, unscrew the retaining nut and remove the entire valve assembly.

### Disassembly

1. Turn the control knob clockwise to the closed position or until it bottoms on the retaining nut.
2. Secure the control knob in a vise (do not overtighten, it could break the control knob) with the needle pointing upward.
3. With a 1/4-inch wrench on the wrench flats of the needle, unscrew the needle and remove it from the control knob stem.

### CAUTION

► With the control knob turned fully into the retaining nut the tension on the spring is relieved. If it is not, the needle could be projected from the control knob stem and cause personal injury.

4. Remove the spring from the control knob stem.
5. Unscrew the control knob and pull it out of the retaining nut.
6. With a small rod (1/4-inch diameter), push the two washers and Teflon o-ring out of the retaining nut.

### Cleaning and Inspection

1. Discard both o-rings. They should be replaced with new ones.
2. Clean the parts in a suitable solvent.
3. Check all components for damage and also check the needle for wear. Replace any damaged or worn parts.

### Assembly

1. Apply a light coating of dielectric grease to a new o-ring and slide it over the threads of the retaining nut until it sets into the thread relief.
2. Apply a light coating of dielectric grease to the control knob threads and screw it into the retaining nut to the closed position or until it bottoms.
3. Place the first washer, a new Teflon o-ring, and then a second washer onto the control knob stem. Slide the components into the retaining nut bore.
4. Place the spring over the control knob stem and into the retaining nut bore.

5. Secure the control knob in a vise with the control knob stem pointing upwards. Apply a small amount of medium strength thread locker to the threads of the control knob stem.
6. Screw the needle onto the control knob stem and with a 1/4-inch wrench, tighten the needle.

## Reinstall

1. Turn the control knob to the open position (screwed fully out, counterclockwise).
2. Screw the retaining nut into the handle by hand. Using a 9/16-inch open-end wrench, secure the retaining nut into the handle.
3. Screw the control knob to its closed position.

## AIR VALVE

-REFER TO FIGURE 21

### Removal

1. Remove the trigger and ground spring from the handle (refer to "Trigger" in the "Maintenance" section).

2. With a standard blade screwdriver, remove the air valve cap from the back of the handle.
3. Remove the compression spring from the back of the air valve rod assembly.
4. From the front of the handle, push the air valve rod assembly rearward until it can be removed by hand from the back of the handle. **Do not use any tools to grip the air valve. This can damage its sealing surface.**

### NOTE

- ▶ A rod (1/8-inch diameter or smaller) can be used to push the assembly out the back of the handle until it can be gripped with the fingers.

5. With a 3/8-inch wrench, completely remove the retaining nut with the internal u-cup seal.

### Cleaning and Inspection

1. Remove the o-ring from the air valve cap.
2. Clean all components with a suitable solvent.
3. Inspect the air valve rod assembly for wear and/or damage. If any wear is found on the air valve rod assembly, it and the u-cup seal must be replaced.




Figure 21: Air Valve



**CAUTION**

► The seal internal to the air valve retaining nut cannot be reused once it has been removed from its holder.

4. Inspect all other parts for damage. Replace any damaged components.
5. Inspect the brass seat in the handle for damage or wear. If damaged or worn, the handle must be replaced. (Refer to "Handle" in the "Maintenance" section.)

### Reinstall

1. Install the new spring loaded u-cup seal, spring side (cup portion) outward, into the air valve retaining nut. Apply a coating of Teflon thread sealant to the threads of the retaining nut and screw it fully into the handle. Use 3/8 open-end wrench to tighten.
2. Apply a thin film of lubricant around the shaft just behind the brass tip of the air valve rod assembly.
3. Install the air valve, rod end first, into the air valve chamber from the back on the left side of the handle and push it through the retaining nut.
4. Install the compression spring onto the back of the air valve.
5. Apply a thin film of lubricant on the o-ring and install it into the thread relief of the air valve cap.
6. Install the assembled air valve cap containing the o-ring seal into the handle using a standard blade screwdriver.

## TRIGGER

### Removal

**NOTE**

► The gun trigger can be replaced either with the gun on-line or removed from service. If the following procedure is to be done online, make sure that all fluid and air sources are shut off to the gun and the pressure in the lines is relieved. Most of all make sure that the power supply is turned off.

### -REFER TO FIGURE 22


1. Remove the two shoulder screws that attach the trigger to the gun.
2. Hold the grounding spring in position and remove the trigger from the gun assembly.
3. Remove the ground spring from the rod portion of the air valve and set it aside for safe keeping.

### Cleaning and Inspection

1. Clean the trigger with a suitable solvent and dry.
2. Inspect the trigger for damage or wear and replace if necessary.

### Reinstall

1. Install the ground spring onto the rod portion of the air valve and hold it in place.
2. Slide the trigger onto the handle and align the holes with the threaded holes in the handle.



**Figure 22: Trigger Removal**

3. Insert the shoulder screws through the holes of the trigger and screw them into the handle by hand.
4. Secure the shoulder screws to the handle using a flat blade screwdriver.

## NEEDLE SHAFT RETURN SPRING REPLACEMENT

### Removal

1. Remove the trigger and ground spring from the gun (refer to "Trigger" in the "Maintenance" section).
2. Loosen the barrel retaining nut and slide it forward on the barrel.
3. Pull the barrel forward until there is enough clearance between the needle shaft spring retainer and the handle to remove the spring.

### Cleaning and Inspection

1. Clean all the components in a suitable solvent and dry.
2. Check all components for wear, fatigue, or damage and replace as required.

### Reinstall

1. Install a new spring into the needle shaft spring retainer.
2. Slide the barrel back into the handle cavity until it seats against the barrel gasket.
3. Check the spring to ensure it has seated into the handle recess and tighten the barrel retaining nut.
4. Reinstall the trigger and ground spring (refer to "Trigger" in the "Maintenance" section).

# LOW VOLTAGE CABLE PLUG ASSEMBLY REPLACEMENT

-REFER TO FIGURE 23




Figure 23: Low Voltage Cable Plug Removal

## Removal

1. Remove the gun from service (refer to "To Remove the Gun from the Work Site").
2. On solvent base guns it might be necessary to remove the fluid tube and fitting before removing the low voltage cable plug assembly. (Refer to "Fluid Tube - Solvent Base Guns".)
3. Use a 3/32-inch hexagon Allen wrench to loosen (DO NOT remove) the set screw that retains the low voltage cable plug assembly to the handle. The set

screw is located toward the bottom of the handle on the front side (see Figure 23).

4. Hold the bottom of the plug assembly and pull it straight out of the handle.

**⚠ CAUTION**

► Trying to twist or unscrew the low voltage cable plug assembly from the handle will damage the low voltage plug assembly and the hook/transformer. If this occurs, both components have to be replaced.

## Cleaning and Inspection

1. The low voltage cable plug assembly should not be cleaned or soaked in any solvents. If the assembly is contaminated, it must be replaced.
2. Examine the low voltage cable plug assembly for damage to the housing, broken wires, and/or broken solder joints. If any are found the assembly must be replaced.
3. Examine the (5) o-rings of the low voltage cable plug assembly and replace any that are damaged.
4. If the old low voltage cable plug assembly is to be reinstalled into the gun, it should be tested first. (Refer to "Low Voltage Control Unit Test Assembly" manual, TE-96-01.)

## Reinstall

1. Apply a light coating of dielectric grease to the (3) o-rings and insert the low voltage cable plug assembly into the handle. (DO NOT push the assembly fully into the handle.)
2. Rotate the plug assembly until the slot in the aluminum housing is aligned with the set screw in the handle.

3. Push the low voltage cable plug assembly into the handle until it seats into the hook/transformer assembly.
4. Tighten the set screw until it seats into the alignment slot of the low voltage cable plug assembly.

## LOW VOLTAGE CABLE REPLACEMENT

### Removal

#### **WARNING**

- ▶ Prior to working and/or performing maintenance on any part of the gun assembly, make sure that the control unit, AVIATOR, or MGS System are turned off (locked and/or tagged out). Also make sure that all residual voltage is drained from the system by grounding the needle/electrode.

1. Using a wrench, unscrew the low voltage cable assembly from the low voltage cable plug assembly in the handle.
2. Remove the low voltage cable assembly from the plug assembly by pulling straight out.
3. Unscrew the low voltage cable assembly from the control unit.
4. Remove the low voltage cable assembly from the fluid and air hose bundle.

### Cleaning and Inspection

1. If prior testing has shown that the low voltage cable assembly is bad, the cable assembly must be replaced.

#### **NOTE**

- ▶ The low voltage cable assembly is not repairable due to its construction. The cable assembly must be replaced.

2. If the low voltage cable assembly has not been tested, it should be tested. (Refer to "Low Voltage Control Unit Test Assembly" manual, TE-96-01.)
3. The low voltage cable assembly can be wiped with a suitable solvent. **DO NOT** soak or submerge the cable assembly in solvent.
4. Check the full length of cable for wear or breaks in the cable sheathe. If any are found, the cable assembly should be replaced.

### Assembly

1. Connect the low voltage cable assembly to the low voltage cable plug assembly of the handle.

#### **CAUTION**

- ▶ Do NOT overtighten the low voltage cable connection to the handgun as damage to plastic parts may occur.

2. Route the low voltage cable assembly back to the low voltage control unit and attach the cable assembly into the air hose/fluid hose bundle.
3. Connect the low voltage cable assembly to the low voltage control unit.

## FLUID TUBE (SOLVENT BASE GUNS)

-REFER TO FIGURE 24

### Removal

1. Remove the gun from service. (Refer to "To Remove the Gun from the Work Site".)
2. At the fluid tube bracket, unscrew the plastic nut from the fitting using a 3/4-inch open end wrench and slide it up the fluid tube.
3. Unscrew the fluid tube connector from the barrel and slide it down the fluid tube.
4. Pull the fluid tube out of the fitting at the fluid tube bracket.




Figure 24: Fluid Tube Components

5. If the fluid tube will not pull out of the fitting, it might be necessary to remove the fluid tube bracket from the gun. (Refer to "Fluid Tube Bracket".)
6. Remove the fluid tube, ferrule, and spacer from the barrel.

### Cleaning and Inspection

1. Clean the fluid tube, associated fittings, and ferrules in a suitable solvent.

#### NOTE

- The inside diameter of the fluid tube should only be cleaned by flushing solvent through it while in service. No attempt should be made to clean the inside diameter of the fluid tube once it is removed from the gun. If there is paint residue in the bore it should be replaced. Also, if the outer surface is contaminated or damaged it should be replaced.

2. Inspect the fluid tube for paint contamination and/or damage. If any is found it should be replaced.

#### CAUTION

- The accumulation of paint on the outer surface of the fluid tube can lead to reduced gun efficiency and/or electrical damage.

### Reinstall

1. At one end of the fluid tube, place the nut and ferrule that will attach to the fluid tube bracket fitting.
2. At the opposite end, install the fluid tube connector, ferrule, and spacer. Place this end of the fluid tube into the barrel and push it into the bore until seated.
3. Slide the spacer and ferrule into the barrel bore. Then screw the fluid tube connector into the barrel by hand.

4. Secure the fluid tube to the barrel using a wrench.
5. Flex the fluid tube slightly until the other end fits into the fitting on the fluid tube bracket. If the fluid tube will not flex enough, loosen the fitting from the bracket.

**NOTE**

► DO NOT overflex the fluid tube into the fitting. This will kink the tube and it will have to be replaced.

6. Slide the nut and ferrule into position to engage the fitting and hand tighten.
7. With a 3/4-inch open end wrench, secure the nut to the fitting.

## FLUID HOSE (SOLVENT BASE GUNS)

### Removal

1. With a 3/4-inch open end wrench, unscrew the fluid hose nut from the fluid tube bracket fitting and remove the fluid hose.
2. Remove the fluid hose from the fluid supply.

### Cleaning and Inspection

1. The outer surface of the fluid hose can be wiped with a suitable solvent.

**NOTE**

► If the fluid hose will not flow solvent when the gun is removed from service, it is plugged and must be replaced. Fluid hoses should be replaced periodically, depending on the type of materials being sprayed.

2. Check the hose outer surface for wear or cuts and replace as necessary.

### Reinstall

1. To reinstall an existing or new fluid hose refer to "Fluid Hose - Solvent Base Guns".

## FLUID HOSE (WATERBORNE GUNS)

### Removal

1. Unscrew the fluid tube connector at the barrel and slide it back.
2. Unscrew the fluid bracket fitting nut and slide it onto the core tubing.
3. Spread the conductive ferrule open and also slide it onto the core tubing.
4. Pull the fluid hose assembly out of the barrel, removing the fluid spacer, ferrule, and fluid tube connector. Then continue pulling the hose through the fluid tube bracket fitting, removing the bracket fitting nut and conductive ferrule.
5. Completely remove the hose assembly from the fitting, then unscrew the hexagon nut and remove the fluid hose fitting from the fluid tube bracket.
6. Disconnect the fluid hose at the fluid supply.


### Cleaning and Inspection

1. The outer surface of the fluid hose can be wiped with a suitable solvent.

**! WARNING**

► The fluid hose should not be soaked in solvent and only nonpolar solvent should be used to clean the outer surface. Soaking or the use of polar solvents can create hazardous conditions that could cause equipment failure and/or personnel injury.


- Inspect the external surfaces of the fluid hose assembly for damage to the outer jacket, inner sheath, or core tubing. If damage such as abrasion, cuts, and/or scratches are found the assembly must be replaced.



**Figure 25: Fluid Hose Components**

## Reinstall

**-REFER TO FIGURES 25 & 26**



**Figure 26: Proper Position - Fluid Tube or Fluid Hose**

## NOTE

► The fluid hose for waterborne guns can only be purchased as a preassembled unit. The assembly of this hose can only be done by certified ITW Ransburg Technicians.

- Insert the fluid hose fitting from the bottom of the fluid tube bracket. With the pin and the mating slot aligned, slide the fitting into place and secure using the hexagon nut.
- Using a new or used fluid hose, insert the shortest end of exposed core tubing into the hexagon side of the fluid hose fitting and push the end through the bore.
- Before installing the tube end into the barrel, place the conductive ferrule, fluid tube bracket fitting nut, fluid tube connector, ferrule, and fluid spacer onto the core tubing.
- Continue sliding the tubing through the fitting and into the barrel. Ensure that it is seated in the barrel chamber. (Refer to Figure 26).

## NOTE

► The conductive ferrule is black and is split down one side.

5. Slide the fluid spacer and ferrule into the barrel. Then screw the fluid tube connector into the barrel chamber and tighten using an adjustable wrench to secure the tubing in place.
6. Spread the conductive ferrule over inner sheath and slide it into the fluid hose fitting. Then slide the fitting nut over the inner sheath and install it onto the fitting. Tighten the nut using an adjustable wrench to secure the fluid hose assembly to the bracket.

## AIR LINE

### Removal

1. With a wrench, hold the air fitting in place and loosen the air hose nut using a second wrench. Completely unscrew the nut and remove the air hose assembly.
2. Disconnect the air hose from the flow switch port at the low voltage control unit.
3. Remove the air hose assembly from the fluid hose and low voltage cable bundle.

### Cleaning and Inspection

1. The outer surface of the air hose assembly can be wiped with a suitable solvent. Do not submerge or soak the air hose in solvent.



### CAUTION

► Soaking or submerging the air hose assembly in solvent can lead to premature failure of the hose assembly.

2. Inspect the air hose for physical damage to the hose and fittings. If any is found, replace the hose assembly.

### Reinstall

1. Connect the air hose to the air fitting of the gun assembly. With a wrench, hold the air fitting in place and tighten the air hose nut using a second wrench.
2. Reroute the air hose back into the fluid hose and low voltage cable bundle.
3. Connect the air hose to the flow switch port marked out on the low voltage control unit.

## FLUID TUBE BRACKET

### Removal

1. For **solvent base guns** remove the fluid tube. (Refer to "Fluid Tube - Solvent Base Guns".)
2. For **waterborne guns** remove the fluid hose. (Refer to "Fluid Hose - Waterborne Guns".)
3. Remove the low voltage cable from the plug assembly.
4. Remove the air hose from the air fitting.
5. With an 11/16-inch open end wrench, unscrew the air fitting from the handle.
6. The fluid tube bracket should come off with the air fitting and o-ring attached.
7. Remove the o-ring from the air fitting stem and pull the air fitting through the fluid tube bracket.

### Cleaning and Inspection

1. Clean the fluid tube bracket in a suitable solvent.
2. Damage to the fluid tube bracket is uncommon. Set it aside for future service.



## Reinstall

1. Insert the air fitting from the bottom of the fluid tube bracket. Lubricate lightly a new o-ring with dielectric and slide it over the air fitting.
2. Position the fluid tube bracket over the low voltage cable plug assembly and screw the air fitting into the handle. Tighten with a wrench, however do not overtighten the fitting causing damage to the handle.
3. Reconnect the low voltage cable to the plug assembly.
4. For solvent base guns, reconnect the fluid tube to the fluid tube bracket fitting. (Refer to "Fluid Tube".)
5. For waterborne guns, connect the fluid hose to the gun. (Refer to "Fluid Hose - Waterborne Guns".)

## TRIGGER ADJUSTMENT




Figure 27: Trigger Adjustment

## NOTE

- The following procedure is to set the sequence of operation for air and fluid as the trigger is actuated. It is very important that atomizing air be introduced before the fluid. If fluid is energized prior to the air, the applicator will spit large paint particles onto the part being coated.
1. Actuate the trigger slowly, watching the sequence of mechanical operation. The trigger set screw should engage the air valve before the strike plate of the trigger contacts the front adjustment nut on the needle shaft assembly.
  2. If the sequence of operation is out of order, ensure that the distance between the back surface of the barrel packing chamber to the back of the hexagon of the needle shaft spring retainer is 11/16-inch. (Refer to Figure 15).
  3. Normally if this distance is correct, the mechanical sequence will function properly. If not, check the assembly for problems such as a missing gasket, loose fluid nozzle, loose needle electrode, or damage to any of these components.
  4. To readjust the 11/16-inch distance, the trigger and ground spring must be removed. Then the hexagon nuts may be loosened using (2) 3/8-inch open-end wrenches.
  5. To delay fluid actuation, increase the 11/16-inch distance or to quicken the actuation of fluid decrease this distance. Be sure not to over adjust in either direction. A distance to great will not allow full needle travel or a distance to short may not allow adequate spring force on the needle valve.
  6. After establishing the proper mechanical sequence of air then fluid actuation, reinstall the ground spring and trigger.

7. Another adjustment is turning the trigger set screw clockwise, reducing the distance required to engage the air valve and counterclockwise to increase the distance. Be sure not to over adjust in either direction.

## FAN AIR ADJUSTMENT

The fan air screw adjustments should be made during normal spray operating conditions. The adjustment of the screw is dependent on the material being sprayed, the desired spray pattern, and the spray technology type. Turning the fan air screw clockwise will close the pattern and turning it counterclockwise will open it up. For additional information on adjusting the spray pattern, refer to "REA Handgun Spray Techniques" manual, IL-246.

## FLUID DELIVERY ADJUSTMENT

Fluid delivery to the spray gun should be made external to it. Some fluid adjustments can be done on the gun by adjusting the trigger stop screw. When the stop is adjusted fully back (clockwise), the spray gun should be at maximum fluid delivery. By turning the trigger stop forward (counterclockwise), the fluid delivery can be reduced.

## ATOMIZING AIR ADJUSTMENT

The atomizing air supplied to the spray gun can only be adjusted external to the gun. There is no means of adjusting the atomizing air pressure at the spray gun.

## NOTES:

## TROUBLESHOOTING GUIDE

General Problem	Possible Cause	Solution
<b>DEFECTIVE SPRAY PATTERN</b>		
<b>Pattern Will Not Shape</b>	<ol style="list-style-type: none"> <li>1. Clogged or faulty fan air valve</li> <li>2. Air passages in gun or air line clogged</li> <li>3. Worn, faulty, or clogged air cap</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean, repair, or replace.</li> <li>2. Blow out, clean, or replace.</li> <li>3. Clean or replace.</li> </ol>
<b>Pattern Heavy at One End</b>	<ol style="list-style-type: none"> <li>1. Clogged or faulty air cap</li> <li>2. Clogged or faulty fluid nozzle</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean or replace.</li> <li>2. Clean or replace.</li> </ol>
<b>Extremely Heavy Spitting or Severely Deformed Pattern</b>	<ol style="list-style-type: none"> <li>1. Wrong air cap/fluid nozzle combination</li> <li>2. Faulty air cap</li> </ol>	<ol style="list-style-type: none"> <li>1. Ensure proper fluid nozzle/air nozzle pressure reducer combinations (see Figure 5).</li> <li>2. Replace.</li> </ol>
<b>No Control of Round Spray Pattern While in Air Spray Mode</b>	<ol style="list-style-type: none"> <li>1. Wrong fan control valve installed</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace with proper fan control valve. See parts list for proper assembly number.</li> </ol>
<b>INADEQUATE DELIVERY</b>		
<b>Air</b>	<ol style="list-style-type: none"> <li>1. Air passages in gun or air line clogged</li> <li>2. Inadequate air source</li> <li>3. Paint in air passage</li> </ol>	<ol style="list-style-type: none"> <li>1. Blow out.</li> <li>2. Increase.</li> <li>3. Clean and blow out.</li> </ol>
<b>Fluid</b>	<ol style="list-style-type: none"> <li>1. Clogged or faulty fluid nozzle</li> <li>2. Clogged passages in gun fluid tube or fluid line</li> <li>3. Insufficient needle/electrode travel</li> <li>4. Low fluid supply pressure</li> <li>5. Clogged fluid filter</li> <li>6. Clogged or obstructed valve or fluid regulator</li> </ol>	<ol style="list-style-type: none"> <li>1. Flush or replace.</li> <li>2. Flush.</li> <li>3. Adjust (see "Trigger Adjustment").</li> <li>4. Increase.</li> <li>5. Clean or replace.</li> <li>6. Clean as required or replace.</li> </ol>

Figure 28: Troubleshooting Guide (Continued on next page)

General Problem	Possible Cause	Solution
<b>LEAKAGE</b>		
<b>Air</b>	1. Defective valve seat or valve spring	1. Clean and lubricate or replace.
<b>Air</b> (At plugged machine holes in body or at air valve cap at rear of body)	1. Loose or defective plugs or cap	1. Tighten or replace Teflon tape.
<b>Fluid</b> (At rear of barrel)	1. Cartridge seal assembly and/or needle/electrode shaft defective	1. See "Barrel Assembly".
<b>Fluid</b> (Slight leak at nozzle when trigger is released)	1. Nozzle not secure 2. Air valve closing before fluid valve	1. Tighten. 2. Adjust needle shaft/electrode travel.
<b>Fluid</b> (Constant at nozzle)	1. Worn or damaged fluid nozzle 2. Worn or damaged needle/electrode 3. Loose fluid nozzle 4. Needle/electrode does not seat when trigger is released	1. Replace fluid nozzle. 2. Replace. 3. Tighten. 4. Adjust (see "Trigger Adjustment").
<b>ELECTRICAL</b>		
<b>Wrap Back</b>	1. Improper target ground 2. Improper spray technique 3. Improper booth exhaust 4. Excessive atomizing air 5. Excessive target distance	1. Trace and correct (1 megohm maximum ground to target resistance). 2. See ITW Ransburg "REA Handgun Spray Techniques" manual, IL-246. 3. Trace and correct. 4. Reduce pressure. 5. Decrease distance between gun and target.
<b>Improper or No High Voltage</b>	1. Faulty low voltage cable connections 2. Faulty transformer/hook assembly 3. Improper or no ground at control unit 4. Faulty barrel/cascade assembly 5. Faulty low voltage cable 6. Faulty control unit	1. Check and secure at the gun and at the control unit. 2. Replace. 3. Trace and correct (1 megohm maximum ground to target resistance). 4. Replace. 5. Replace. 6. See the control unit manual.

**Figure 28: Troubleshooting Guide (Continued)**

General Problem	Possible Cause	Solution
<b>ELECTRICAL (Continued)</b>		
<b>Improper or No High Voltage (Continued)</b>	7. Check fuses	7. Replace fuse.
	8. Is the power turned on?	8. Check power supply.
	9. Is the atomizing air turned on?	9. Check air regulator.
	10. Is the gun triggered?	10. Check gun trigger.
	11. Is the hook transformer on?	11. Check hook transformer switch.
	12. Is the paint too conductive?	12. Check conductivity of paint.
<b>Isolation System Grounded Out</b>	1. Failed fluid hose	1. Replace fluid hose.
	2. Isolation stand or charged equipment too close to ground	2. Provide adequate ground distance.

**Figure 28: Troubleshooting Guide (Continued)**

# PARTS IDENTIFICATION





Figure 29a: 75785 Solvent Base (Standard) and 75979 Solvent Base (AVIATOR/MGS)

## 75785 SOLVENT BASE REA-90 STANDARD MODEL IDENTIFICATION

The REA-90 and REA-90L handguns are available with a short or a long trigger, and with various LV cable and fluid, and air hose lengths as follows:




\* **Note:** The long trigger cannot be used with the 45° bracket.

---

## 75979 SOLVENT BASE REA-90 AVIATOR/MGS MODEL IDENTIFICATION

The REA-90 and REA-90L handguns are available with a short or a long trigger, and with various LV cable and fluid, and air hose lengths as follows:



\* **Note:** The long trigger cannot be used with the 45° bracket.

<b>REA-90 &amp; 90L SPRAY GUNS (75785 &amp; 75979) - PARTS LIST (Figure 29a)</b>		
<b>Item #</b>	<b>Description</b>	<b>Part #</b>
	<b>REA-90 Delta Handgun (Air Spray) Complete Assembly</b> (Solvent Base Systems Only):	
	For Standard 9040	75785S-BBC1D
	For AVIATOR / MGS	75979S-BBC1D
	<b>REA-90L Delta Handgun (HVLP) Complete Assembly</b> (Solvent Base Systems Only):	
	For Standard 9040	75785L-BBC1D
	For AVIATOR / MGS	75979L-BBC1D
1 <sup>2</sup>	<b>Retaining Ring:</b>	
	Swirl	4903-00
	HVLP, Air Spray, and Round	73569-00
2 <sup>2</sup>	<b>Air Cap:</b>	
	Flat Pattern, HVLP	75601-00
	Flat Pattern, Air Spray	4904-xx*
	Round Pattern, Swirl	70899-00
	Round Pattern, Round	LREA0002-00
3 <sup>2</sup>	<b>Fluid Nozzle:</b>	
	Flat Pattern, HVLP	75600-01
	Flat Pattern, Air Spray	4907-xx*
	Round Pattern, Swirl	70898-00
	Round Pattern, Round	LREA0003-00
4	Barrel, REA-90	75791-00
5	Reducer, Pressure, Air Spray, Black	74963-02
6	Reducer, Pressure, HVLP, White	74963-03
7	Nut, Retainer, Barrel	75323-00
8	Ring, Retaining, Barrel	75326-00
9	Electrode Assembly	70430-00
10	-----	-----
11 <sup>3</sup>	Seal Assembly, Cartridge, Non-Adjustable, REA	78626-00
12	-----	-----
13 <sup>3</sup>	Shaft Assembly, 2-Piece Needle, REA	78627-04
14 <sup>3</sup>	Tube, Packing Adjustment	18842-01
15	Retainer, Needle Seal, Rear	78629-00
16 <sup>3</sup>	O-Ring, Solvent Resistant	7554-08
17	Seal, Lip, Spring Loaded (2 Required)	10051-05
18	Spacer, Seal	78630-00
19	-----	-----
20	Nut, Packing	78631-00
21	Nut, Locking, Trigger Adjustment	78632-00
22	Gasket, Barrel	72360-00
23	Handle, Sub-Assembly, Conductive Plastic, REA	78641-00
24	Set Screw, Cup Point, Internal Serration, #10-32	19603-16F
25	<b>Hook Assembly:</b>	
	Hook / Transformer without On-Off Switch	71202-00
	Hook / Transformer with On-Off Switch	71202-01
	Kit, Switch Replacement	78086-00
	Lens, Glass, Threaded	72532-00
26	<b>Fluid Tube / Bracket:</b>	
	Offset (All Triggers)	20979-00
	45° (2-Finger Trigger Only)	70441-00
27	Spring, Compression	72474-01
28 <sup>4</sup>	Nut, Retaining, Air Valve	78635-00
29	-----	-----

See "Parts List Bullet Definition Table" on page 62.

(Continued on Next Page)



**REA-90 & 90L SPRAY GUNS (75785 & 75979) - PARTS LIST  
(Figure 29a)**

Item #	Description	Part #
30 <sup>3</sup>	Rod Assembly, Air Valve	79310-00
31	Spring, Compression	17130-00
32	-----	-----
33	Cap, Air Valve	79317-00
34	<b>Fan Valve Assembly</b> (Contains Items 35 thru 41)	
	Air Spray	18851-01
	HVLP	75133-00
35	Needle, Air Spray	78788-00
	Needle, HVLP	75132-00
36	Spring, Compression	18829-00
37	Washer (2 Required)	18833-00
38	O-Ring, Solvent Proof	13076-08
39	O-Ring, Solvent Resistant	72209-05
40 <sup>4</sup>	Nut, Retaining, Fan Valve	77019-00
41	Knob, Control	77018-00
42	<b>Trigger Assembly:</b>	
	Short, 2-Finger (All Brackets)	18871-00
	Long, 4-Finger (Offset Bracket Only)	20974-00
	Set Screw (Not Shown)	73647-02
43	Screw, Shoulder (2 Required)	6144-00
44	Nut, Hexagon	7733-07
45	Knob, Trigger Stop	77017-00
46	Spring, Compression	20977-00
47 <sup>3</sup>	Screw, Adjustment, Trigger Stop	20976-00
48	-----	-----
49	-----	-----
50	-----	-----
51 <sup>4</sup>	Cap, Valve Spring (2 Required)	77015-00
52	Spacer, Fluid	76993-00
53	Ferrule	72308-00
54	Nut, Connector, Fluid Tube	72309-00
55	<b>Fluid Tube:</b>	
	For 20979-00 Offset Bracket, .093 I.D. (8-3/8" Required)	9704-16
	For 70441-00, 45° Bracket, .093 I.D. (8-15/16" Required)	9704-16
56	Nut and Ferrule	3587-03
57	Nut, Jam	10553-06
58	<b>Fluid Tube Bracket Bulkhead Fitting:</b>	
	For 20979-00 Offset Bracket	70399-00
	For 70441-00, 45° Bracket	70442-00
69	O-Ring, Solvent Resistant (2 Required)	7554-11
70	Fitting, Air Inlet, 1/4" - 18 NPSM	18847-01
71 <sup>1</sup>	<b>Hose Assembly:</b> (Includes Items 72 thru 76)	
	Air	14614-xx*
	Fluid	14615-xx*
72 <sup>1</sup>	<b>Line Hose (Bulk Hose - No Fittings):</b>	
	Air, 5/16" I.D.	6919-xx*
	Fluid, 1/4" I.D.	77031-xx*
73	<b>Line Fitting Assembly:</b>	
	Air (Sold Only in Sets) (2 Required)	LSFI0027-00
	Fluid (Includes Items 74 thru 76)	14628-00
74	Ferrule, Fluid (For Fluid Hose Assembly)	7617-00
75	Nut, Fluid (For Fluid Hose Assembly)	14599-00
76	Union, Stem, Fluid (For Fluid Hose Assembly)	7623-00

See "Parts List Bullet Definition Table" on page 62.

(Continued on Next Page)

<b>REA-90 &amp; 90L SPRAY GUNS (75785 &amp; 75979) - PARTS LIST (Figure 29a)</b>		
<b>Item #</b>	<b>Description</b>	<b>Part #</b>
77 <sup>1</sup>	<b>Low Voltage Cable Assembly:</b>	
	For Standard 9040 / MGS	78084-xx*
	For AVIATOR - All Units	78085-xx*
78	<b>Plug Assembly:</b>	
	For Standard 9040	76875-13
	For AVIATOR	76875-12
	For MGS	76875-11
79	O-Ring, Solvent Resistant	7554-08
80	O-Ring, Solvent Resistant	7554-12
81	<b>Coiled Fluid Tube:</b>	
	.093" I.D.	75228-01
	.250" I.D.	75228-02
	.125" I.D.	75228-03
82	Retainer, Spring, Needle Shaft	78633-00
83	Spring, Compression	78636-00
84	-----	-----
85	Grip, Handle, Soft-Touch	78696-00
86	-----	-----

<b>PARTS LIST BULLET DEFINITION TABLE (Figure 29a)</b>	
*	xx = Specify length when ordering.
1	Dash number (-xx) reads in feet (example: -36 = 36 feet). These items are available in standard lengths of 36, 50, 75, and 100 feet. When ordering cable 76876-xx and 76878-xx, use footage for -xx.
2	See nozzle selection chart (Figure 5) for dash number (-xx) identification.
3	Apply dielectric grease (LSCH0009-00) when assembling as noted.
4	Apply 7969-10 (or suitable liquid or ribbon Teflon thread sealant) when assembling as noted.

**NOTES:**





Figure 29b: 75786 Waterborne (Standard) and 75982 Waterborne (AVIATOR)


## 75786 WATERBORNE REA-90 STANDARD MODEL IDENTIFICATION

The REA-90 and REA-90L handguns are available with a short or a long trigger, and with various LV cable and fluid, and air hose lengths as follows:



## 75982 WATERBORNE REA-90 AVIATOR MODEL IDENTIFICATION

The REA-90 and REA-90L handguns are available with a short or a long trigger, and with various LV cable and fluid, and air hose lengths as follows:



<b>REA-90 &amp; 90L SPRAY GUNS (75786 &amp; 75982) - PARTS LIST (Figure 29b)</b>		
<b>Item #</b>	<b>Description</b>	<b>Part #</b>
	<b>REA-90 Delta Handgun (Air Spray) Complete Assembly</b> (Waterborne Systems Only):	
	For Standard 9040	75786S-BBC21
	For AVIATOR	75982S-BBC21
	<b>REA-90L Delta Handgun (HVLP) Complete Assembly</b> (Waterborne Systems Only):	
	For Standard 9040	75786L-BBC21
	For AVIATOR	75982L-BBC21
1 <sup>2</sup>	<b>Retaining Ring:</b>	
	Swirl	4903-00
	HVLP, Air Spray, and Round	73569-00
2 <sup>2</sup>	<b>Air Cap:</b>	
	Flat Pattern, HVLP	75601-00
	Flat Pattern, Air Spray	4904-xx*
	Round Pattern, Swirl	70899-00
	Round Pattern, Round	LREA0002-00
3 <sup>2</sup>	<b>Fluid Nozzle:</b>	
	Flat Pattern, HVLP	75600-01
	Flat Pattern, Air Spray	4907-xx*
	Round Pattern, Swirl	70898-00
	Round Pattern, Round	LREA0003-00
4	Barrel, REA-90	75791-00
5	Reducer, Pressure, Air Spray, Black	74963-02
6	Reducer, Pressure, HVLP, White	74963-03
7	Nut, Retainer, Barrel	75323-00
8	Ring, Retaining, Barrel	75326-00
9	Electrode Assembly	70430-00
10	-----	-----
11 <sup>3</sup>	Seal Assembly, Cartridge, Non-Adjustable, REA	78626-00
12	-----	-----
13 <sup>3</sup>	Shaft Assembly, 2-Piece Needle, REA	78627-04
14 <sup>3</sup>	Tube, Packing Adjustment	18842-01
15	Retainer, Needle Seal, Rear	78629-00
16 <sup>3</sup>	O-Ring, Solvent Resistant	7554-08
17	Seal, Lip, Spring Loaded (2 Required)	10051-05
18	Spacer, Seal	78630-00
19	-----	-----
20	Nut, Packing	78631-00
21	Nut, Locking, Trigger Adjustment	78632-00
22	Gasket, Barrel	72360-00
23	Handle, Sub-Assembly, Conductive Plastic, REA	78641-00
24	Set Screw, Cup Point, Internal Serration, #10-32	19603-16F
25	<b>Hook Assembly:</b>	
	Hook / Transformer without On-Off Switch	71202-00
	Hook / Transformer with On-Off Switch	71202-01
	Kit, Switch Replacement	78086-00
	Lens, Glass, Threaded	72532-00
26	<b>Fluid Tube / Bracket:</b>	
	Offset (All Triggers)	20979-00
27	Spring, Compression	72474-01
28 <sup>4</sup>	Nut, Retaining, Air Valve	78635-00
29	-----	-----
30 <sup>3</sup>	Rod Assembly, Air Valve	79310-00

See "Parts List Bullet Definition Table" on page 68.

(Continued on Next Page)

**REA-90 & 90L SPRAY GUNS (75786 & 75982) - PARTS LIST  
(Figure 29b)**

Item #	Description	Part #
31	Spring, Compression	17130-00
32	-----	-----
33	Cap, Air Valve	79317-00
34	<b>Fan Valve Assembly</b> (Contains Items 35 thru 41)	
	Air Spray	18851-01
	HVLP	75133-00
35	Needle, Air Spray	78788-00
	Needle, HVLP	75132-00
36	Spring, Compression	18829-00
37	Washer (2 Required)	18833-00
38	O-Ring, Solvent Proof	13076-08
39	O-Ring, Solvent Resistant	72209-05
40 <sup>4</sup>	Nut, Retaining, Fan Valve	77019-00
41	Knob, Control	77018-00
42	<b>Trigger Assembly:</b>	
	Short, 2-Finger (All Brackets)	18871-00
	Long, 4-Finger (Offset Bracket Only)	20974-00
	Set Screw (Not Shown)	73647-02
43	Screw, Shoulder (2 Required)	6144-00
44	Nut, Hexagon	7733-07
45	Knob, Trigger Stop	77017-00
46	Spring, Compression	20977-00
47 <sup>3</sup>	Screw, Adjustment, Trigger Stop	20976-00
48	-----	-----
49	-----	-----
50	-----	-----
51 <sup>4</sup>	Cap, Valve Spring (2 Required)	77015-00
59	<b>Waterborne Fluid Hose Assembly:</b> (Includes Items 60 thru 68)	
	3/16" I.D.	72306-xx
	1/4" I.D.	74180-xx
60	Spacer, Fluid	76993-00
61	Ferrule	72308-00
62	Nut, Connector, Fluid Tube	72309-00
63 <sup>5</sup>	Nut & Ferrule	3587-02
64	Ferrule, Conductive	72315-00
65	Nut, Jam	10553-05
66	Fitting, Bulkhead, Bracket, Fluid Hose	72310-00
67	Connector	6241-06
68	Fitting, Swivel	7787-03
69	O-Ring, Solvent Resistant (2 Required)	7554-11
70	Fitting, Air Inlet, 1/4" - 18 NPSM	18847-01
71 <sup>1</sup>	<b>Hose Assembly:</b> (Includes Items 72 thru 73)	
	Air	14614-xx*
72 <sup>1</sup>	<b>Line Hose (Bulk Hose - No Fittings):</b>	
	Air, 5/16" I.D.	6919-xx*
73	<b>Line Fitting Assembly:</b>	
	Air (Sold Only in Sets) (2 Required)	LSFI0027-00
77 <sup>1</sup>	<b>Low Voltage Cable Assembly:</b>	
	For Standard 9040 / MGS	78084-xx*
	For AVIATOR - All Units	78085-xx*
78	<b>Plug Assembly:</b>	
	For Standard 9040	76875-13
	For AVIATOR	76875-12
79	O-Ring, Solvent Resistant	7554-08

See "Parts List Bullet Definition Table" on page 68.

(Continued on Next Page)

**REA-90 & 90L SPRAY GUNS (75786 & 75982) - PARTS LIST  
(Figure 29b)**

Item #	Description	Part #
80	O-Ring, Solvent Resistant	7554-12
82	Retainer, Spring, Needle Shaft	78633-00
83	Spring, Compression	78636-00
84	-----	-----
85	Grip, Handle, Soft-Touch	78696-00
86	-----	-----

**PARTS LIST BULLET DEFINITION TABLE (Figure 29b)**

- \* xx = Specify length when ordering.
- 1 Dash number (-xx) reads in feet (example: -36 = 36 feet). These items are available in standard lengths of 36, 50, 75, and 100 feet. When ordering cable 76876-xx and 76878-xx, use footage for -xx.
- 2 See nozzle selection chart (Figure 5) for dash number (-xx) identification.
- 3 Apply dielectric grease (LSCH0009-00) when assembling as noted.
- 4 Apply 7969-10 (or suitable liquid or ribbon Teflon thread sealant) when assembling as noted.
- 5 Discard the existing ferrule of the compression nut subassembly.



**NOTES:**

<b>RECOMMENDED SPARE PARTS - REA-90 &amp; 90L SPRAY GUNS</b>						
Description	Part Number	No. of Guns				Notes
		1-2	3-4	5-6	7-8	
Rebuild Kit	78929-01	1	2	2	3	
Wrench, Nozzle	19749-00	2	2	4	4	
Barrel Nut	75323-00	1	2	2	3	Fits handle with 1-7/8" diameter threads
Barrel Ring	75326-00	1	2	2	3	Fits handle with 1-7/8" diameter threads
Shoulder Screw	6144-00	2	2	4	4	
Hook / Transformer	71202-xx	1	2	2	3	Replace xx with -01 for transformer w/ switch, -00 for transformer without switch
Fluid Nozzle	4907-xx	1	2	3	4	Replace xx with 44, 45, 46, 47, or 48
Air Cap	4904-xx	1	2	3	4	Replace xx with 63, 98, or 65R
Fluid Nozzle	75600-01	1	2	3	4	For use with HVLP only
Air Cap	75601-00	1	2	3	4	For use with HVLP only
Air Cap	75756-00	1	2	3	4	For use with HVLP only
Cap Retaining Ring	73569-00	1	2	2	3	Used on caps 63, 98, 65R, 75601-00, and 75756-00 only
Low Voltage Cable (Std/MGS)	78084-xx	1	1	2	2	xx must be replaced with desired length of 36, 50, 75, or 100 feet
Low Voltage Cable (Aviator)	78085-xx	1	1	2	2	xx must be replaced with desired length of 36, 50, 75, or 100 feet
Disposable Gun Cover	GC-100-K5	1	2	3	4	
Electrode	70430-00	2	4	6	8	

**Figure 30: Recommended Spare Parts**

<b>MISC. PARTS - REA-90 &amp; 90L SPRAY GUNS</b>		
Item #	Description	Part #
Accessories	Loctite, Medium Strength	7969-00
	Dielectric Grease	LSCH0009-00
	Special Multi-Purpose Gun Wrench	19749-00
	Push Pull Fan Control, Air Spray	72118-00
	Disposable Gun Cover	GC-100-K5

**Figure 31: Misc. Parts**

<b>SERVICE KITS - REA-90 &amp; 90L SPRAY GUNS</b>		
<b>Item #</b>	<b>Description</b>	<b>Part #</b>
Kits	<b>Air Cap Conversion Kit, Air Spray</b> (Contains 4904-65R Air Cap, 4907-44 Nozzle, 73569-00 Retaining Ring)	73570-01
	<b>Air Cap Conversion Kit, Air Spray</b> (Contains 4904-65R Air Cap, 4907-45 Nozzle, 73569-00 Retaining Ring)	73570-02
	<b>Air Cap Conversion Kit, HVLP</b> (Contains 75601-00 Air Cap, 75600-01 Nozzle, 73569-00 Retaining Ring)	73571-01
	<b>HVLP Atomizer Air Cap Test Kit</b>	75137-01
	<b>Air Spray to HVLP Conversion Kit*</b> (Contains 75133-00 Fan Control Valve Assembly, 74963-03 White Pressure Reducer, 73569-00 Retaining Ring) With 75600-01 Fluid Nozzle & 75601-00 Air Cap With 75600-02 Fluid Nozzle & 75756-00 Air Cap With 75600-03 Fluid Nozzle & 75756-00 Air Cap	75734-01 75734-02 75734-03
	<b>HVLP to Air Spray Conversion Kit*</b> (Contains 74963-02 Black Pressure Reducers, 18851-01 Fan Control Valve Assembly, 4904-65R Air Cap, 4907-45 Nozzle, 73569-00 Retaining Ring)	75733-00
	<b>REA-90 Gun Rebuild Kit</b> (Contains the following parts): Soft Parts Kit, 78929-00 (1 Supplied) Needle Shaft, 78627-04 (1 Supplied) Tube, Packing, 18842-01 (1 Supplied) Electrode, 70430-00 (1 Supplied)	<b>78929-01</b>
	<b>REA-90 Gun Rebuild Soft Parts Kit</b> (Contains the following parts): U-Cup Seal, 10051-05 (2 Supplied) O-Ring, Teflon, 13076-08 (1 Supplied) O-Ring, Teflon, 13076-10 (1 Supplied) O-Ring, Teflon, 13076-13 (1 Supplied) Conductive Sponge, 14061-05 (2 Supplied) Conductive Sponge, 14061-08 (1 Supplied) Cartridge Seal, 78626-00 (1 Supplied) Gasket, REA III & IV Only, 18872-00 (1 Supplied) Grease, LSCH0009-00 (1 Supplied) Gasket, REA-70 & 90 Only, 72360-00 (1 Supplied) O-Ring, 7554-08 (2 Supplied) O-Ring, 7554-10 (2 Supplied) O-Ring, 7554-11 (3 Supplied) O-Ring, 7554-12 (1 Supplied) O-Ring, 7554-28 (1 Supplied) O-Ring, 7554-33 (1 Supplied) Cup, Packing, 7723-06 (1 Supplied) Gasket, Barrel Ext., REA-100A Only, 72526-00 (1 Supplied)	<b>78929-00</b>
	<b>Solvent Proof O-Ring Kit for 76875-xx Plug Assembly</b> (Contains the following parts): O-Ring, 79001-09 (1 Supplied) O-Ring, 79001-07 (1 Supplied) O-Ring, 79001-06 (3 Supplied) Instruction Sheet, 77697-00 (1 Supplied)	<b>77696-00</b>

\* For use with barrels marked with ▲ on fluid inlet only.

**Figure 32: Service Kits**

---

# WARRANTY POLICIES

---

## LIMITED WARRANTY

ITW Ransburg will replace or repair without charge any part and/or equipment that falls within the specified time (see below) because of faulty workmanship or material, provided that the equipment has been used and maintained in accordance with ITW Ransburg's written safety and operating instructions, and has been used under normal operating conditions. Normal wear items are excluded.

**THE USE OF OTHER THAN ITW RANSBURG APPROVED PARTS, VOID ALL WARRANTIES.**

**SPARE PARTS:** One hundred and eighty (180) days from date of purchase, except for rebuilt parts (any part number ending in "R") for which the warranty period is ninety (90) days.

**EQUIPMENT:** When purchased as a complete unit, (i.e., guns, power supplies, control units, etc.), is one (1) year from date of purchase.

**WRAPPING THE APPLICATOR, ASSOCIATED VALVES AND TUBING, AND SUPPORTING HARDWARE IN PLASTIC, SHRINK-WRAP, OR ANY OTHER NON-APPROVED COVERING, WILL VOID THIS WARRANTY.**

**FLUID HANDLING:** One (1) year from date of purchase (i.e., Totalizer, CCV Valves, etc.).

**AIR BEARING ROTATORS:** Fifteen thousand (15,000) hours or three (3) years, whichever occurs first. Warranty period begins on the date of purchase.

**ITW RANSBURG'S ONLY OBLIGATION UNDER THIS WARRANTY IS TO REPLACE PARTS THAT HAVE FAILED BECAUSE OF FAULTY WORKMANSHIP OR MATERIALS. THERE ARE NO IMPLIED WARRANTIES NOR WARRANTIES OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ITW RANSBURG ASSUMES NO LIABILITY FOR INJURY, DAMAGE TO PROPERTY OR FOR CONSEQUENTIAL DAMAGES FOR LOSS OF GOODWILL OR PRODUCTION OR INCOME, WHICH RESULT FROM USE OR MISUSE OF THE EQUIPMENT BY PURCHASER OR OTHERS.**

## EXCLUSIONS:

If, in ITW Ransburg's opinion the warranty item in question, or other items damaged by this part was improperly installed, operated or maintained, ITW Ransburg will assume no responsibility for repair or replacement of the item or items. The purchaser, therefore will assume all responsibility for any cost of repair or replacement and service related costs if applicable.

# APPENDIX

## PAINT AND SOLVENT SPECIFICATIONS

	REA™ / EFM™ EVOLVER	REM™ / M90™	NO. 2 HAND GUN	TURBODISK™	AEROBELL® II*** AEROBELL® AEROBELL® 33 RMA-101™
RECOMMENDED VISCOSITY USING A ZAHN NO. 2	18 TO 30 SEC	18 TO 30 SEC	20 TO 60 SEC	20 TO 60 SEC	20 TO 60 SEC
PAINT ELECTRICAL RESISTANCE**	.1 MΩ TO ∞	.1 MΩ TO ∞	.1 TO 1 MΩ	.1 MΩ TO ∞	.1 MΩ TO ∞
RECOMMENDED DELIVERY (UP TO)	1000 cc/min	1500 cc/min	180 cc/min	1000 cc/min	500 cc/min

### GUIDE TO USABLE SOLVENT SELECTION

Chemical Name	Common Name	Category	Flash Point†† (TCC)	*CAS Number	Evap. Rate†	Elec. Res.**
DICHLOROMETHANE	Methylene Chloride	Chlorinated Solvents		75-09-2	14.5	HIGH
VM & P NAPHTHA	Naptha	Aliphatic Hydrocarbons	65°F	8030-30-6	10	HIGH
ACETONE		Ketones	-18°F	67-64-1	5.6	LOW
METHYL ACETATE		Esters	90°F	79-20-9	5.3	LOW
BENZENE		Aromatic Hydrocarbons	12°F	71-43-2	5.1	HIGH
ETHYL ACETATE		Esters	24°F	141-78-6	3.9	MEDIUM
2-BUTANONE	MEK	Ketones	16°F	78-93-3	3.8	MEDIUM
ISO-PROPYL ACETATE		Esters	35°F	108-21-4	3.4	LOW
ISOPROPYL ALCOHOL	IPA	Alcohols	53°F	67-63-0	2.5	LOW
2-PENTANONE	MPK	Ketones	104°F	107-87-9	2.5	MEDIUM
METHANOL	Methyl Alcohol	Alcohols	50°F	67-56-1	2.1	LOW
PROPYL ACETATE	n-Propyl Acetate	Esters	55°F	109-60-4	2.1	LOW
TOLUOL	Toluene	Aromatic Hydrocarbons	48°F	108-88-3	1.9	HIGH
METHYL ISOBUTYL KETONE	MIBK	Ketones	60°F	108-10-1	1.6	MEDIUM
ISOBUTYL ACETATE		Esters	69°F	110-19-0	1.5	LOW
ETHANOL	Ethyl Alcohol	Alcohols		64-17-5	1.4	LOW
<b>BUTYL ACETATE</b>		<b>Esters</b>	<b>78°F</b>	<b>123-86-4</b>	<b>1.0</b>	<b>LOW</b>
ETHYLBENZENE		Aromatic Hydrocarbons	64°F	100-41-4	.89	HIGH
1-PROPANOL	n-Propyl Alcohol	Alcohols	74°F	71-23-8	.86	LOW
2-BUTANOL	sec.-Butyl Alcohol	Alcohols	72°F	78-92-2	.81	LOW
XYLOL	Xylene	Aromatic Hydrocarbons	79°F	1330-02-07	.80	HIGH
AMYLACETATE		Esters	106°F	628-63-7	.67	MEDIUM
2-METHYLPROPANOL	iso-Butyl Alcohol	Alcohols	82°F	78-83-1	.62	LOW
METHYL AMYL ACETATE		Esters	96°F	108-84-9	.50	LOW
5-METHYL-2-HEXANONE	MIAK	Ketones	96°F	110-12-3	.50	MEDIUM
1-BUTANOL	n-Butyl Alcohol	Alcohols	95°F	71-36-3	.43	LOW
2-ETHOXYETHANOL		Glycol Ethers	164°F	110-80-5	.38	LOW
2-HEPTANONE	MAK	Ketones	102°F	110-43-0	.40	MEDIUM
CYCLOHEXANONE		Ketones	111°F	108-94-1	.29	MEDIUM
AROMATIC-100	SC#100	Aromatic Hydrocarbons	111°F		.20	HIGH
DIISOBUTYL KETONE	DIBK	Ketones	120°F	108-83-8	.19	MEDIUM
1-PENTANOL	Amyl Alcohol	Alcohols		71-41-0	.15	LOW
DIACETONE ALCOHOL		Ketones	133°F	123-42-2	.12	LOW
2-BUTOXYETHANOL	Butyl Cellosolve	Glycol Ethers	154°F	111-76-2	.07	LOW
CYCLOHEXANOL		Alcohols	111°F	108-93-0	.05	LOW
AROMATIC-150	SC#150	Aromatic Hydrocarbons	149°F		.004	HIGH
AROMATIC-200		Aromatic Hydrocarbons	203°F		.003	HIGH

\* CAS Number: Chemical Abstract Service Number.

\*\* Electrical Resistance using the ITW Ransburg Meter.

\*\*\* Solvent Base Configuration Only.

† Information Obtained From: <http://solvdb.ncms.org>

†† The lowest temperature at which a volatile fluid will ignite.

**Evaporation Rate is Based Upon Butyl Acetate Having a Rate of 1.0**

© 05/2004 Illinois Tool Works Inc. All rights reserved.

**NOTE:** Chart provides resistance and control information that we feel is necessary when using ITW Ransburg equipment.

**VISCOSITY CONVERSION CHART**

Poise	Centipoise	DuPont Parlin 7	DuPont Parlin 10	Fisher 1	Fisher 2	Ford Cup 3	Ford Cup 4	Gardner - Holdt Bubble	Gardner - Lithographic	Krebs Unit KU	Saybolt Universal SSU	Zahn 1	Zahn 2	Zahn 3	Zahn 4	Zahn 5	Sears Craftsman Cup	Din Cup 4
.1	10	27	11	20			5	A-4			60	30	16					10
.15	15	30	12	25			8	A-3			80	34	17					11
.2	20	32	13	30	15	12	10				100	37	18					12
.25	25	37	14	35	17	15	12	A-2			130	41	19					13
.3	30	43	15	39	18	19	14	A-1			160	44	20					14
.4	40	50	16	50	21	25	18	A			210	52	22				19	15
.5	50	57	17		24	29	22			30	260	60	24				20	16
.6	60	64	18		29	33	25	B		33	320	68	27				21	18
.7	70		20		33	36	28			35	370		30				23	21
.8	80		22		39	41	31	C		37	430		34				24	23
.9	90		23		44	45	32			38	480		37	10			26	25
1.0	100		25		50	50	34	D		40	530		41	12	10		27	27
1.2	120		30		62	58	41	E		43	580		49	14	11		31	31
1.4	140		32			66	45	F		46	690		58	16	13		34	34
1.6	160		37				50	G		48	790		66	18	14		38	38
1.8	180		41				54		000	50	900		74	20	16		40	43
2.0	200		45				58	H		52	1000		82	23	17	10	44	46
2.2	220						62	I		54	1100			25	18	11		51
2.4	240						65	J		56	1200			27	20	12		55
2.6	260						68			58	1280			30	21	13		58
2.8	280						70	K		59	1380			32	22	14		63
3.0	300						74	L		60	1475			34	24	15		68
3.2	320							M			1530			36	25	16		72
3.4	340							N			1630			39	26	17		76
3.6	360							O		62	1730			41	28	18		82
3.8	380										1850			43	29	19		86
4.0	400							P		64	1950			46	30	20		90
4.2	420										2050			48	32	21		95
4.4	440							Q			2160			50	33	22		100
4.6	460							R		66	2270			52	34	23		104
4.8	480								00	67	2380			54	36	24		109
5.0	500							S		68	2480			57	37	25		112
5.5	550							T		69	2660			63	40	27		124
6.0	600							U		71	2900			68	44	30		135
7.0	700									74	3375				51	35		160
8.0	800								0	77	3380				58	40		172
9.0	900							V		81	4300				64	45		195
10.0	1000							W		85	4600					49		218
11.0	1100									88	5200					55		
12.0	1200									92	5620					59		

<b>VISCOSITY CONVERSION CHART (Continued)</b>																		
Poise	Centipoise	DuPont Parlin 7	DuPont Parlin 10	Fisher 1	Fisher 2	Ford Cup 3	Ford Cup 4	Gardner - Holdt Bubble	Gardner - Lithographic	Krebs Unit KU	Saybolt Universal SSU	Zahn 1	Zahn 2	Zahn 3	Zahn 4	Zahn 5	Sears Craftsman Cup	Din Cup 4
13.0	1300							X		95	6100					64		
14.0	1400								1	96	6480							
15.0	1500									98	7000							
16.0	1600									100	7500							
17.0	1700									101	8000							
18.0	1800							Y			8500							
19.0	1900										9000							
20.0	2000									103	9400							
21.0	2100										9850							
22.0	2200										10300							
23.0	2300							Z	2	105	10750							
24.0	2400									109	11200							
25.0	2500							Z-1		114	11600							
30.0	3000									121	14500							
35.0	3500							Z-2	3	129	16500							
40.0	4000									133	18500							
45.0	4500							Z-3		136	21000							
50.0	5000										23500							
55.0	5500										26000							
60.0	6000							Z-4	4		2800							
65.0	6500										30000							
70.0	7000										32500							
75.0	7500										35000							
80.0	8000										37000							
85.0	8500										39500							
90.0	9000										41000							
95.0	9500										43000							
100.0	10000							Z-5	5		46500							
110.0	11000										51000							
120.0	12000										55005							
130.0	13000										60000							
140.0	14000										65000							
150.0	15000							Z-6			67500							
160.0	16000										74000							
170.0	17000										83500							
180.0	18000										83500							
190.0	19000										88000							
200.0	20000										93000							
300.0	30000										140000							

**Note:** All viscosity comparisons are as accurate as possible with existing information. Comparisons are made with a material having a specific gravity of 1.0.

<b>VOLUMETRIC CONTENT OF HOSE OR TUBE (English Units)</b>							
I.D. (inches)	cc/ft.	Cross Section (in. <sup>2</sup> )	Length				
			5ft. (60")	10ft. (120")	15ft. (180")	25ft. (300")	50ft. (600")
1/8	2.4	.012	.003 gal. .4 fl. oz.	.006 gal. .8 fl. oz.	.010 gal. 1.2 fl. oz.	.016 gal. 2.0 fl. oz.	.032 gal. 4.1 fl. oz.
3/16	5.4	.028	.007 gal. .9 fl. oz.	.014 gal. 1.8 fl. oz.	.022 gal. 2.8 fl. oz.	.036 gal. 4.6 fl. oz.	.072 gal. 9.2 fl. oz.
1/4	9.7	.049	.013 gal. 1.6 fl. oz.	.025 gal. 3.3 fl. oz.	.038 gal. 4.9 fl. oz.	.064 gal. 8.2 fl. oz.	.127 gal. 16.3 fl. oz.
5/16	15.1	.077	.020 gal. 2.5 fl. oz.	.040 gal. 5.1 fl. oz.	.060 gal. 7.6 fl. oz.	.100 gal. 12.7 fl. oz.	.199 gal. 25.5 fl. oz.
3/8	21.7	.110	.029 gal. 3.7 fl. oz.	.057 gal. 7.3 fl. oz.	.086 gal. 11.0 fl. oz.	.143 gal. 18.4 fl. oz.	.287 gal. 36.7 fl. oz.
1/2	38.6	.196	.051 gal. 6.5 fl. oz.	.102 gal. 13.1 fl. oz.	.153 gal. 19.6 fl. oz.	.255 gal. 32.6 fl. oz.	.510 gal. 65.3 fl. oz.

<b>VOLUMETRIC CONTENT OF HOSE OR TUBE (Metric Units)</b>							
I.D. (mm)	cc/m	Cross Section (mm <sup>2</sup> )	Length				
			1.5m	3.0m	4.5m	6.0m	7.5m
3.6	10.2	10.2	15.3 cc	30.5 cc	45.8 cc	61.1 cc	76.3 cc
5.6	24.6	24.6	36.9 cc	73.9 cc	110.8 cc	147.8 cc	184.7 cc
6.8	36.3	36.3	54.5 cc	109.0 cc	163.4 cc	217.9 cc	272.4 cc
8.8	60.8	60.8	91.2 cc	182.5 cc	273.7 cc	364.9 cc	456.2 cc

© 05/2004 Illinois Tool Works Inc. All rights reserved.



## NOTES:

# NOTES:

# MANUAL CHANGE SUMMARY

This manual was published to replace Service Manual **AH-94-04.4**, *REA-90 and 90L Spray Guns*, to make the following changes:

1. **"Maintenance"** section - revised:
  - Figure 21
  - "Gun Repair"
  - "Equipment Required"
  - "Air Valve - Removal, Cleaning and Inspection, Reinstall"
  
2. **"Parts Identification"** section revised:
  - Figures 29a, 29b, 30, 31, & 32
  - Parts Lists for Figures 29a & 29b (items 30, 31, 33, 84, & 86)

**Manufacturing**

1910 North Wayne Street  
Angola, Indiana 46703-9100  
Telephone: 260/665-8800  
Fax: 260/665-8516

**Technical/Service Assistance**

Automotive Assembly and Tier I  
Industrial Systems  
Ransburg Guns

Telephone: 800/ 626-3565 Fax: 419/ 470-2040  
Telephone: 800/ 233-3366 Fax: 419/ 470-2071  
Telephone: 800/ 233-3366 Fax: 419/ 470-2071

**Technical Support Representative will direct you to the appropriate telephone number for ordering Spare Parts.**